

Fenner®




Fenner® QD:Neo


Installation and Operating Instructions

AC Variable Speed Drive
0.75kW - 160kW
200 - 480 Volt 1 & 3 Phase


Easy Start Up Guide: QD:Neo IP20



Easy Start Up Guide: QD:Neo IP55




Easy Start Up Guide: QD:Neo IP66



Display

Keypad Operation can be found on page 20

IMPORTANT SAFETORQUE OFF (STO)



Link the terminals as shown, through the emergency stop circuit contacts

Control terminals



Run - Stop

Close the switch to run (enable), open to stop

10K Speed Pot

Motor Cable

For correct cable size, see technical data on pages 41 and 42
Observe the maximum permissible motor cable length
For motor cable lengths > 50 metres, an output filter is recommended
Use a screened (shielded cable). The shield should be bonded to earth at both ends

Motor Connection

Check for Star or Delta Connection
Enter the Motor Nameplate data into the drive parameters as follows:

Motor Rated Voltage : P1-07

Motor Rated Current : P1-08

Motor Rated Frequency : P1-09

Motor Rated Speed (Optional) : P1-10

AC Supply Connection

200 - 240 Volts +/- 10%
380 - 480 Volts +/- 10%

Fuses or MCB

Check the drive rating information on pages 41 & 42

1. INTRODUCTION		5.8 Changing the Language in OLED Display	23
1.1 Important Safety Information	7	5.9 Resetting Parameters to Factory Default	23
		5.10 Terminal Control	24
2. GENERAL INFORMATION AND RATINGS	8	5.11 Keypad Control	25
2.1 Drive Model Numbers - IP20	8	5.12 Operating in Sensorless Vector Speed Control	25
2.2 Drive Model Numbers - IP55	8		
2.3 Drive Model Numbers - IP66	9	6. PARAMETERS	26
3. MECHANICAL INSTALLATION	10	6.1 Parameter Set Overview	26
3.1 General	10	6.2 Parameter Group 1 - Basic Parameters	26
3.2 Before Installation	10		
3.3 UL Compliant Installation	10	7. DIGITAL INPUT FUNCTIONS	28
3.4 Mechanical dimensions and mounting IP20	10	7.1 Digital Input Configuration Parameter P1-13	28
3.5 Guidelines for enclosure mounting IP20	11		
3.6 Mounting the Drive IP20	11	8. EXTENDED PARAMETERS	30
3.7 Mechanical Dimensions IP55	12	8.1 Parameter Group 2 - Extended Parameters	30
3.8 Guidelines for Mounting IP55	12	8.2 Parameter Group 3 - PID Control	34
3.9 Mechanical Dimensions IP66	13	8.3 Parameter Group 4 - High Performance Motor Control	35
3.10 Guidelines for Mounting IP66	13	8.4 Parameter Group 5 - Communication	36
3.11 Removing the Terminal Cover	14	8.5 Parameter Group 0 - Monitoring Parameters	37
4. ELECTRICAL INSTALLATION	16	9. SERIAL COMMUNICATIONS	39
4.1 Grounding the Drive	16	9.1 RS-485 Communications	39
4.2 Wiring Precautions	16	9.2 ModBus RTU Communications	40
4.3 Incoming Power Connection	16		
4.4 Operation of 3 Phase drives from a Single Phase Supply	17	10. TECHNICAL DATA	41
4.5 Drive and Motor Connection	17	10.1 Environmental	41
4.6 Motor Terminal Box Connections	17	10.2 Output and Current Ratings	41
4.7 Motor Thermistor Connection	18	10.3 Additional Information for UL Approved Installation	42
4.8 Control Terminal Wiring	18		
4.9 Control Diagram	18	11. TROUBLESHOOTING	43
4.10 Control Terminal Connections	19	11.1 Fault Messages	43
5. MANAGING THE KEYPAD	20		
5.1 Keypad Layout and Function	20		
5.2 Changing Parameters	20		
5.3 Advanced Keypad Operation Shortcuts	21		
5.4 Drive Operating Displays	21		
5.5 Keypad Layout and Function OLED	22		
5.6 Drive Operating Display	22		
5.7 Accessing and Changing Parameter Values	22		

Declaration of Conformity

ERIKS Industrial Services Ltd hereby states that the Fenner QD product range conforms to the relevant safety provisions of the Low Voltage Directive 2006/95/EC and the EMC Directive 2004/108/EC and has been designed and manufactured in accordance with the following harmonised European standards:

EN 61800-5-1: 2003	Adjustable speed electrical power drive systems. Safety requirements. Electrical, thermal and energy.
EN 61800-3 2 nd Ed: 2004	Adjustable speed electrical power drive systems. EMC requirements and specific test methods.
EN 55011:2007	Limits and Methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio-frequency equipment (EMC).
EN60529:1992	Specifications for degrees of protection provided by enclosures.

Drive Type / Rating	EMC Category		
	Cat C1	Cat C2	Cat C3
1 Phase, 230 Volt Input	No additional filtering required. Use shielded motor cable.		
3 Phase, 400 Volt Input	Use external filter	No additional filtering required	
	Use shielded motor cable		
Note	For motor cable lengths greater than 100m, an output dv / dt filter must be used. For further information contact your Fenner distributor. Vector speed and torque control modes may not operate correctly with long motor cables and output filters. It is recommended to operate in V/F mode only for cable length exceeding 50m		

Electromagnetic Compatibility

All Fenner drives are designed with high standards of EMC in mind. All versions suitable for operation on Single Phase 230 volt and Three Phase 400 volt supplies and intended for use within the European Union are fitted with an internal EMC filter. This EMC filter is designed to reduce the conducted emissions back into the supply via the power cables for compliance with harmonised European standards.

It is the responsibility of the installer to ensure that the equipment or system into which the product is incorporated complies with the EMC legislation of the country of use. Within the European Union, equipment into which this product is incorporated must comply with the EMC Directive 2004/108/EC. When using an Fenner drive with an internal or optional external filter, compliance with the following EMC Categories, as defined by EN61800-3:2004 can be achieved:

All rights reserved. No part of this User Guide may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information storage or retrieval system without permission in writing from the publisher.

Copyright ERIKS Industrial Services Ltd © 2011

ERIKS Industrial Services Ltd, Amber Way, Halesowen, West Midlands, B62 8WG

The manufacturer accepts no liability for any consequences resulting from inappropriate, negligent or incorrect installation, or adjustment of the optional operating parameters of the drive or from mismatching of the drive to the motor.

The contents of this User Guide are believed to be correct at the time of printing. In the interest of a commitment to a policy of continuous improvement, the manufacturer reserves the right to change the specification of the product or its performance or the contents of the User Guide without notice.

All Fenner QD Series products carry a 2-year warranty, valid from the date of manufacture. This date is visible on the product rating label.

1. Introduction

1.1 Important Safety Information

Please read the important safety information below, and all Warning and Caution Information elsewhere in this manual.

	Danger: Indicates a risk of electric shock, which, if not avoided, could result in damage to the equipment and possible injury or death.
--	--

This variable speed drive product (Fenner QD:Neo) is intended for professional incorporation into complete equipment or systems as part of a fixed installation. If installed incorrectly it may present a safety hazard. The Fenner QD:Neo uses high voltages and currents, carries a high level of stored electrical energy, and is used to control mechanical plant that may cause injury. Close attention is required to system design and electrical installation to avoid hazards in either normal operation or in the event of equipment malfunction. Only qualified electricians are allowed to install and maintain this product.

System design, installation, commissioning and maintenance must be carried out only by personnel who have the necessary training and experience. They must carefully read this safety information and the instructions in this Guide and follow all information regarding transport, storage, installation and use of the drive, including the specified environmental limitations.

Do not perform any flash test or voltage withstand test on the drive. Any electrical measurements required should be carried out with the drive disconnected.

Electric shock hazard! Disconnect and ISOLATE the Fenner QD:Neo before attempting any work on it. High voltages are present at the terminals and within the drive for up to 10 minutes after disconnection of the electrical supply. Always ensure by using a suitable multimeter that no voltage is present on any drive power terminals prior to commencing any work.

Where supply to the drive is through a plug and socket connector, do not disconnect until 10 minutes have elapsed after turning off the supply.

Ensure correct earthing connections. The earth cable must be sufficient to carry the maximum supply fault current which normally will be limited by the fuses or MCB. Suitably rated fuses or MCB should be fitted in the mains supply to the drive, according to any local legislation or codes.

Do not carry out any work on the drive control cables whilst power is applied to the drive or to the external control circuits.

	Danger: Indicates a potentially hazardous situation other than electrical, which if not avoided, could result in damage to property.
---	--

Within the European Union, all machinery in which this product is used must comply with Directive 98/37/EC, Safety of Machinery. In particular, the machine manufacturer is responsible for providing a main switch and ensuring the electrical equipment complies with EN60204-1.

The level of integrity offered by the Fenner QD:Neo control input functions (excluding the 'Safe Torque Free Input') – for example stop/start, forward/reverse and maximum speed, is not sufficient for use in safety-critical applications without independent channels of protection. All applications where malfunction could cause injury or loss of life must be subject to a risk assessment and further protection provided where needed.

The driven motor can start at power up if the enable input signal is present.

The STOP function does not remove potentially lethal high voltages. ISOLATE the drive and wait 10 minutes before starting any work on it. Never carry out any work on the Drive, Motor or Motor cable whilst the input power is still applied.

The drive can be programmed to operate the driven motor at speeds above or below the speed achieved when connecting the motor directly to the mains supply. Obtain confirmation from the manufacturers of the motor and the driven machine about suitability for operation over the intended speed range prior to machine start up.

Do not activate the automatic fault reset function on any systems whereby this may cause a potentially dangerous situation.

The Fenner QD:Neo has an Ingress Protection rating of IP20 or IP55 depending on the model. IP20 units must be installed in a suitable enclosure.

Fenner QD: Neo drives are intended for indoor use only.

When mounting the drive, ensure that sufficient cooling is provided. Do not carry out drilling operations with the drive in place, dust and swarf from drilling may lead to damage.

The entry of conductive or flammable foreign bodies should be prevented. Flammable material should not be placed close to the drive

Relative humidity must be less than 95% (non-condensing).

Ensure that the supply voltage, frequency and no. of phases (1 or 3 phase) correspond to the rating of the drive as delivered.

Never connect the mains power supply to the Output terminals U, V, W.

Do not install any type of automatic switchgear between the drive and the motor

Wherever control cabling is close to power cabling, maintain a minimum separation of 100 mm and arrange crossings at 90 degrees

Ensure that all terminals are tightened to the appropriate torque setting

Do not attempt to carry out any repair of the Fenner QD:Neo. In the case of suspected fault or malfunction, contact your local Fenner distributor.

2. General Information and Ratings

2.1 Drive Model Numbers - IP20

572N20P7

Series & Inverter Supply Rated
Enclosure Type Voltage Power

200-240V 10% - 1 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
572N20P7	0.75	2	4.3	2
572N21P5	1.5	2	7	2
572N22P2	2.2	2	10.5	2

200-240V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
572N30P7	0.75	2	4.3	2
572N31P5	1.5	2	7	2
572N32P2	2.2	2	10.5	2
572N3P40	4	3	18	3

380-480V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
572N40P7	0.75	1	2.2	2
572N41P5	1.5	2	4.1	2
572N42P2	2.2	3	5.8	2
572N44P0	4	5	9.5	2
572N45P5	5.5	7.5	14	3
572N47P5	7.5	10	18	3
572N4011	11	15	24	3

2.2 Drive Model Numbers - IP55

200-240V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
575N35P5	5.5	7.5	25	4
575N37P5	7.5	10	39	4
575N3011	11	15	46	4
575N3015	15	20	61	5
575N3018	18.5	25	72	5
575N3022	22	30	90	6
575N3030	30	40	110	6
575N3037	37	50	150	6
575N3045	45	60	180	6
575N3055	55	75	202	7
575N3075	75	100	240	7
575N3090	90	120	300	7

380-480V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
575N4011	11	15	25	4
575N4015	15	20	30	4
575N4018	18.5	25	39	4
575N4022	22	30	46	4
575N4030	30	40	61	5
575N4037	37	50	72	5
575N4045	45	60	90	6
575N4055	55	75	110	6
575N4075	75	100	150	6
575N4090	90	150	180	6
575N4110	110	160	202	7
575N4132	132	200	240	7
575N4160	160	250	300	7

2.3 Drive Model Numbers - IP66

200-240V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
576N20P7	0.75	1	4.3	2
576N21P5	1.5	2	7	2
576N22P2	2.2	3	10.5	2

380-480V 10% - 3 Phase Input

kW Model with Filter	Kw	HP	Output Current (A)	Frame Size
576N40P7	0.75	1	2.2	2
576N41P5	1.5	2	4.1	2
576N42P2	2.2	3	5.8	2
576N44P0	4	5	9.5	2
576N44P5	5.5	7.5	14	3
576N47P5	7.5	10	18	3

3. Mechanical Installation

3.1 General

- The Fenner QD:Neo should be mounted in a vertical position only on a flat, flame resistant vibration free mounting using the integral holes or DIN rail clip (Frame Size 2 only).
- The drive must be installed in a pollution degree 1 or 2 environment only.
- Do not mount flammable material close to the Fenner QD:Neo
- Ensure that the minimum cooling air gaps, as detailed in section 3.5 and 3.8 are left clear
- Ensure that the ambient temperature range does not exceed the permissible limits for the Fenner QD:Neo given in section 10.1
- Provide suitable clean, moisture and contaminant free cooling air sufficient to fulfil the cooling requirements of the Fenner QD:Neo

3.2 Before Installation


- Carefully Unpack the Fenner QD:Neo and check for any signs of damage. Notify the shipper immediately if any exist.
- Check the drive rating label to ensure it is of the correct type and power requirements for the application.
- Store the drive in its box until required. Storage should be clean and dry and within the temperature range -40°C to +60°C.

3.3 UL Compliant Installation

Note the following for UL compliant installation:

- The drive can be operated within an ambient temperature range as stated in section 10.1
- For IP20 units, installation is required in a pollution degree 1 environment
- For IP55 units, installation in a pollution degree 2 environment is permissible
- UL Listed ring terminals / lugs must be used for all bus bar and grounding connections

3.4 Mechanical Dimensions and Mounting - IP20 Units



Drive Size	A		B		C		D		E		F		G		H		I		J	
	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
2	221	8.70	204	8.15	137	5.39	209	8.23	5.3	0.21	185	5.91	112	4.29	63	2.48	5.5	0.22	10	0.39
3	261	10.28	246	9.69	-	-	247	9.72	6	0.24	205	6.89	131	5.16	80	3.15	5.5	0.22	10	0.39


Control terminal torque settings: All Sizes: 0.8Nm

Power Terminal Torque Settings: All sizes: 1Nm

3.5 Guidelines for Enclosure Mounting (IP20 Units)

- Installation should be in a suitable enclosure, according to EN60529 or other relevant local codes or standards.
- Enclosures should be made from a thermally conductive material.
- Where vented enclosures are used, there should be venting above the drive and below the drive to ensure good air circulation – see the diagram below. Air should be drawn in below the drive and expelled above the drive.
- In any environments where the conditions require it, the enclosure must be designed to protect the Fenner QD:Neo against ingress of airborne dust, corrosive gases or liquids, conductive contaminants (such as condensation, carbon dust, and metallic particles) and sprays or splashing water from all directions.
- High moisture, salt or chemical content environments should use a suitably sealed (non-vented) enclosure.

The enclosure design and layout should ensure that the adequate ventilation paths and clearances are left to allow air to circulate through the drive heatsink. Fenner recommend the following minimum sizes for drives mounted in non-ventilated metallic enclosures:-



Drive Size	X Above and Below		Y Either Side		Z Between		Recom- med Airflow
	mm	in	mm	in	mm	in	
2	75	2.95	50	1.97	46	1.81	11
3	100	3.94	50	1.97	52	2.05	26

Note:

Dimension Z assumes that the drives are mounted side-by-side with no clearance


Typical drive heat-losses are 3% of operating load conditions

Above are guidelines only and the operating ambient temperature of the drive MUST be maintained at all times.

3.6 Mounting the Drive (IP20 Units)

- IP20 units are intended for installation within a control cabinet.
- When mounting with screws
 - Using the drive as a template, or the dimensions shown above, mark the locations for drilling
 - Ensure that when mounting locations are drilled, the dust from the drilling does not enter the drive
 - Mount the drive to the cabinet backplate using suitable M5 mounting screws
 - Position the drive, and tighten the mounting screws securely
- When DIN rail mounting (Frame Size 2 Only)
 - Locate the DIN rail mounting slot on the rear of the drive onto the top of the DIN rail first
 - Press the bottom of the drive onto the DIN rail until the lower clip attaches to the DIN rail
 - If necessary, use a suitable flat blade screwdriver to pull the DIN rail clip down to allow the drive to mount securely on the rail
 - To remove the drive from the DIN rail, use a suitable flat blade screwdriver to pull the release tab downwards, and lift the bottom of the drive away from the rail first.

3.7 Mechanical Dimensions (IP55 Units)



Drive Size	A		B		C		D		E		F		G		H		I	
	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
4	440	17.32	418	16.46	423	16.65	8	0.315	240	9.449	171	6.732	110	4.331	4.25	0.167	75	0.295
5	540	21.26	515	20.28	520	20.47	8	0.315	270	10.63	235	9.252	175	6.89	4.25	0.167	75	0.295
6	865	34.06	830	32.68	840	33.07	10	0.394	330	12.99	330	12.99	200	7.874	5.5	0.217	11	0.433
7	1280	50.39	1245	49.02	1255	49.41	10	0.394	360	14.17	330	12.99	200	7.874	5.5	0.217	11	0.433

Control terminal torque settings: All Sizes: 0.5Nm

Power Terminal Torque Settings: Frame Size 4: 1.2-1.5Nm


Frame Size 5: 2.5 - 4.5Nm

Frame Size 7: 8Nm

Frame Size 8: 8Nm

3.8 Guidelines for Mounting (IP55 Units)

- Before mounting the drive, ensure that the chosen location meets the environmental condition requirements for the drive shown in section 10.1
- The drive must be mounted vertically, on a suitable flat surface
- The minimum mounting clearances as shown in the table below must be observed
- The mounting site and chosen mountings should be sufficient to support the weight of the drive



Drive Size	X Above and Below		Y Either Side	
	mm	in	mm	in
4	200	7.87	10	0.39
5	200	7.87	10	0.39
6	200	7.87	10	0.39
7	200	7.87	10	0.39


Note:

Typical drive heat-losses are 3% of operating load conditions

Above are guidelines only and the operating ambient temperature of the drive MUST be maintained at all times.

Using the drive as a template, or the dimensions shown above, mark the locations required for drilling
The drive should be mounted using M8 (Frame sizes 4 & 5) or M10 (Frame Sizes 6 & 7) mounting bolts

3.9 Mechanical Dimensions (IP66 Units)




Drive Size	A		B		D		E		F		G		H		I		J	
	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
2	257	10.1	220	8.67	200	7.9	29	1.1	238	9.37	188	7.4	176	6.9	4.2	0.2	8.5	0.3
3	310	12.2	277	10.9	252	9.9	33	1.3	256	10.1	211	8.3	198	7.8	4.2	0.2	8.5	0.3

Control terminal torque settings: All Sizes: 0.8Nm

Power Terminal Torque Settings: Frame Size 2: 1.2-1.5Nm

3.10 Guidelines for Mounting (IP66 Units)

- Before mounting the drive, ensure that the chosen location meets the environmental condition requirements for the drive shown in section 10.1
- The drive must be mounted vertically, on a suitable flat surface
- The minimum mounting clearances as shown in the table below must be observed
- The mounting site and chosen mountings should be sufficient to support the weight of the drive



Drive Size	X Above and Below		Y Either Side	
	mm	in	mm	in
4	200	7.87	10	0.39
5	200	7.87	10	0.39
6	200	7.87	10	0.39
7	200	7.87	10	0.39

Note:

Typical drive heat-losses are 3% of operating load conditions

Above are guidelines only and the operating ambient temperature of the drive MUST be maintained at all times.

Using the drive as a template, or the dimensions shown above, mark the locations required for drilling. The drive should be mounted using M8 (Frame sizes 4 & 5) or M10 (Frame Sizes 6 & 7) mounting bolts

3.11 Removing the Terminal Cover



3.11.1 Frame Size 2



3.11.2 Frame Size 3




Terminal Cover Release Screws




3.11.3 Frame Size 4

3.11.4 Frame Size 5


Using a suitable flat blade screwdriver, rotate the four retaining screws indicated until the screw slot is vertical.



Using a suitable flat blade screwdriver, rotate the four retaining screws indicated until the screw slot is vertical.



3.11.5 Frame Size 6 & 7



Remove the screws indicated, lift the cover forwards and off. To refit the cover, slide the top locating lugs upwards under the top cover, then refasten the lower cover screws.

4. Electrical Installation

4.1 Grounding the Drive



This manual is intended as a guide for proper installation. ERIKS cannot assume responsibility for the compliance or the non-compliance to any code, national, local or otherwise, for the proper installation of this drive or associated equipment. A hazard of personal injury and/or equipment damage exists if codes are ignored during installation.



This Fenner QD:Neo contains high voltage capacitors that take time to discharge after removal of the main supply. Before working on the drive, ensure isolation of the main supply from line inputs. Wait ten (10) minutes for the capacitors to discharge to safe voltage levels. Failure to observe this precaution could result in severe bodily injury or loss of life.



Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

4.1.1 Grounding Guidelines

The ground terminal of each drive should be individually connected DIRECTLY to the site ground bus bar (through the filter if installed). Fenner QD:Neo ground connections should not loop from one drive to another, or to, or from any other equipment. Ground loop impedance must confirm to local industrial safety regulations. To meet UL regulations, UL approved ring crimp terminals should be used for all ground wiring connections.

The drive Safety Ground must be connected to system ground. Ground impedance must conform to the requirements of national and local industrial safety regulations and/or electrical codes. The integrity of all ground connections should be checked periodically.

4.1.2 Protective Earth Conductor

The Cross sectional area of the PE Conductor must be at least equal to that of the incoming supply conductor.

4.13 Safety Ground

This is the safety ground for the drive that is required by code. One of these points must be connected to adjacent building steel (girder, joist), a floor ground rod, or bus bar. Grounding points must comply with national and local industrial safety regulations and/or electrical codes.

4.14 Motor Ground

The motor ground must be connected to one of the

ground terminals on the drive.

4.15 Ground Fault Monitoring

As with all inverters, a leakage current to earth can exist. The Fenner QD:Neo is designed to produce the minimum possible leakage current whilst complying with worldwide standards. The level of current is affected by motor cable length and type, the effective switching frequency, the earth connections used and the type of RFI filter installed. If an ELCB (Earth Leakage Circuit Breaker) is to be used, the following conditions apply: -

- A Type B Device must be used
- The device must be suitable for protecting equipment with a DC component in the leakage current
- Individual ELCBs should be used for each drive

4.16 Shield Termination (Cable Screen)

The safety ground terminal provides a grounding point for the motor cable shield. The motor cable shield connected to this terminal (drive end) should also be connected to the motor frame (motor end). Use a shield terminating or EMI clamp to connect the shield to the safety ground terminal.

4.2. Wiring Precautions

Connect the Fenner QD:Neo according to section 4.3, ensuring that motor terminal box connections are correct. There are two connections in general: Star and Delta. It is essential to ensure that the motor is connected in accordance with the voltage at which it will be operated. For more information, refer to section 4.6 Motor Terminal Box Connections.

It is recommended that the power cabling should be 4-core PVC-insulated screened cable, laid in accordance with local industrial regulations and codes of practice.

4.3. Incoming Power Connection

- For 1 phase supply, power should be connected to L1/L, L2/N.
- For 3 phase supplies, power should be connected to L1, L2, and L3. Phase sequence is not important.
- For compliance with CE and C Tick EMC requirements, a symmetrical shielded cable is recommended.
- A fixed installation is required according to IEC61800-5-1 with a suitable disconnecting device installed between the Fenner QD:Neo and the AC Power Source. The disconnecting device must conform to the local safety code / regulations (e.g. within Europe, EN60204-1, Safety of machinery).
- The cables should be dimensions according to any local codes or regulations. Guideline dimensions are given in section 10.4.
- Suitable fuses to provide wiring protection of the input power cable should be installed in the incoming supply line, according to the data in section 10.4. The fuses must comply with any local codes or regulations in place. In general, type gG (IEC 60269) or UL type T fuses are

suitable; however in some cases type aR fuses may be required. The operating time of the fuses must be below 0.5 seconds.

- Where allowed by local regulations, suitably dimensioned type B MCB circuit breakers of equivalent rating may be utilised in place of fuses, providing that the clearing capacity is sufficient for the installation.
- When the power supply is removed from the drive, a minimum of 30 seconds should be allowed before re-applying the power. A minimum of 5 minutes should be allowed before removing the terminal covers or connection.
- The maximum permissible short circuit current at the Fenner QD:Neo Power terminals as defined in IEC60439-1 is 100kA.
- An optional Input Choke is recommended to be installed in the supply line for drives where any of the following conditions occur:-
 - The incoming supply impedance is low or the fault level / short circuit current is high
 - The supply is prone to dips or brown outs
 - An imbalance exists on the supply (3 phase drives)
 - The power supply to the drive is via a busbar and brush gear system (typically overhead Cranes).
- In all other installations, an input choke is recommended to ensure protection of the drive against power supply faults. Part numbers are shown in the table.

Supply	Frame Size	AC Input Inductor
230 Volt	2	QCHOKE-2S
1 Phase	3	QCHOKE-3S
400 Volt	2	QCHOKE-2
3 Phase	3	QCHOKE-3

4.4. Operation of 3 Phase Drives from a Single Phase Supply

A special function of the Fenner QD:Neo allows all drives designed for operation on 3 phase supplies to be operated on a single phase supply of the correct rated voltage at up to 50% of the nominal capacity. For Example, Model Number 575N4045 can be operated on a single phase supply, 380 – 480 volts, with the maximum output current limited to 45 Amps. The supply should be connected to the L1 and L2 terminals of the drive.

4.5. Drive and Motor Connection

- The motor should be connected to the drive U, V, and W terminals using a suitable 3 or 4 core cable. Where a 3 core cable is utilised, with the shield operating as an earth conductor, the shield must have a cross sectional



area at least equal to the phase conductors when they are made from the same material. Where a 4 core cable is utilised, the earth conductor must be of at least equal cross sectional area and manufactured from the same material as the phase conductors.

- The motor earth must be connected to one of the Fenner QD:Neo earth terminals.
- For compliance with the European EMC directive, a suitable screened (shielded) cable should be used. Braided or twisted type screened cable where the screen covers at least 85% of the cable surface area, designed with low impedance to HF signals are recommended as a minimum. Installation within a suitable steel or copper tube is generally also acceptable.
- The cable screen should be terminated at the motor end using an EMC type gland allowing connection to the motor body through the largest possible surface area
- Where drives are mounted in a steel control panel enclosure, the cable screen may be terminated directly to the control panel using a suitable EMC clamp or gland, as close to the drive as possible.
- For IP55 drives, connect the motor cable screen to the internal ground clamp

4.6. Motor Terminal Box Connections

Most general purpose motors are wound for operation on dual voltage supplies. This is indicated on the nameplate of the motor.


This operational voltage is normally selected when installing the motor by selecting either STAR or DELTA connection. STAR always gives the higher of the two voltage ratings.

Incoming Supply Voltage	Motor Nameplate Voltages	Connection	
230	230/400	Delta	
400	400/690		
400	230/400	Star	

4.7 Motor Thermistor Connection

Where a thermistor is to be used, it should be connected as follows:

Control Terminal Strip



Additional information


- Compatible thermistor: PTC Type, 2.5Ω trip level
- Use a setting of P1-13 that have Input 5 function as External Trip, e.g. P1-13=6. Refer to section 7 for further details.

4.8 Control Terminal Wiring


- All analog signal cables should be suitably shielded. Twisted pair cables are recommended.
- Power and Control Signal cables should be routed separately where possible, and must not be routed parallel to each other
- Signal levels of different voltages e.g. 24 Volt DC and 110 Volt AC, should not be routed in the same cable.
- Maximum control terminal tightening torque is 0.5Nm.

4.9 Connection Diagram

4.9.1 Power Terminal Designations



4.9.2 Control Terminal Connections and Factory Settings



4.10 Control Terminal Connections

Main Terminal Strip			
1	+24V	+24V User Input / Output	100mA User Output
2	DI 1	Input 1	Digital 8 - 30 Volt DC
3	DI 2	Input 2	Digital 8 - 30 Volt DC
4	DI 3	Input 3	Digital 8 - 30 Volt DC
5	+10V	+10 Volt User Output	10mA for user potentiometer
6	AI 1	Input 4	Digital 8 to 30DC/Analog Input 1, -10 to +10V, 0/4 to 20mA or =24VDC Digital
7	0V	0 Volt Common	
8	AO1	Output 1	1st Analog/Digital Output, 0 to 10V, 4 to 20mA or +24DC Digital
9	0V	0 Volt Common	
10	AI 2	Input 5	Digital 8 to 30V DC / Analog Input 2, 0 to 10V, 0/4 to 20mA or
11	AO2	Output 2	Analog input 2 / Digital Output, 0 to 10V, 4 to 20mA, Digital 24V
12	STO+	Drive hardware inhibit	"Safe" 24V input - must be linked to ext +24 Volt (18-30 Volt) DC to enable power stage
13	STO-	Inhibit 0V input	0V return for the 24V "Safe" (STO)
Additional Terminal Strip			
14	RL1-C	Relay Output 1 Common	Relay contacts, 250V AC, 30V DC, 5A
15	RL1-NO	Relay Output 1 NO	Relay contacts, 250V AC, 30V DC, 5A
16	RL1-NC	Relay Output 1 NC	Relay contacts, 250V AC, 30V DC, 5A
17	RL2-A	Relay Output 2 Common	Relay contacts, 250V AC, 30V DC, 5A
18	RL2-B	Relay Output 2 NO	Relay contacts, 250V AC, 30V DC, 5A

5. Managing the Keypad

The drive is configured and its operation monitored via the keypad and display

5.1 Keypad Layout and Function - Standard LED Keypad

	NAVIGATE	Used to display real-time information, to access and exit parameter edit mode and to store parameter changes
	UP	Used to increase speed in real-time mode or to increase parameter values in parameter edit mode
	DOWN	Used to decrease speed in real-time mode or to decrease parameter values in parameter edit mode
	RESET/STOP	Used to reset a tripped drive. When in keypad mode is used to Stop a running drive
	START	When in keypad mode, used to Start a stopped drive or to reverse the direction of rotation if bidirectional keypad mode is enabled.

5.2 Changing Parameters

Procedure	Display Shows
Power on drive	Stop
Press and hold the for >2 seconds	P 1-01
Press the key	P 1-02
The and can be used to select the desired parameter	P 1-03 etc...
Select the required parameter, e.g. P1-02	P 1-02
Press the button	0.0
Use the and keys to adjust the value, e.g. set to 10	10.0
Press the key	P 1-02
The parameter value is now adjusted and automatically stored. Press the key for >2 seconds to return to operating mode	Stop

5.3 Advanced Keypad Operation Shortcuts


Function	When Display Shows	Press	Result	Example
Fast selection of Parameter Groups Note: Parameter Group Access must be enabled P1-14=101	Px-xx	 + 	The next highest Parameter group is selected	Display shows P 1- 10 Press  +  Display shows P2- 0 1
	Px-xx	 + 	The next lowest Parameter group is selected	Display shows P2-25 Press  +  Display shows P 1- 0 1
Select lowest Group Parameter	Px-xx	 + 	The first parameter of a group is selected	Display shows P 1- 10 Press  +  Display shows P 1- 0 1
Set Parameter to minimum value	Any numerical value (whilst editing a parameter value)	 + 	The parameter is set to the minimum value	When editing P 1- 0 1 Display shows 50.0 Press  +  Display shows 0.0
Adjusting individual digits within a parameter value	Any numerical value (whilst editing a parameter value)	 + 	Individual parameter digits can be adjusted	When editing P 1- 10 Display shows 0 Press  +  Display shows .0 Press  Display shows 10 Press  +  Display shows . 10 Press  Display shows 1 10 etc

5.4 Drive Operating Displays

Display	Status
StoP	Drive mains power applied, but no Enable or Run signal applied
Auto-t	Motor Autotune in progress
H x.x	Drive running, display shows output frequency (Hz)
I x.x	Drive running, display shows motor current (Amps)
P x.x	Drive running, display shows motor power (kW)
C x.x	Drive running, display shows customer selected units, see parameters P2-21 and P2-22
Err-24	Drive mains power not present, external 24 Volt control power supply present only
INH	Output power hardware inhibited, Safe Torque Off function activated. External links are required to the STO inputs (terminals 12 and 13) as shown in section 4.8 Control Terminals Connection Diagram
P-DEF	Parameters reset to factory default settings
U-DEF	Parameters reset to User default settings
For drive fault code displays, refer to section 11.1 on page xx	

5.5 Keypad Layout and Function - Optional OLED Keypad (IP55 units Only)





For IP55 drives, an optional Multi Language OLED display keypad may be specified at the time of order, option code - Tx.

OLED Display		
Main Displayed Parameter Shows which of the selectable parameters is currently being shown on the main display, e.g. motor speed, motor current etc. Operating Information Provides a real time display of key operating information, e.g. output current and power Start Button When in Hand mode, used to start the drive. Stop/Reset Button Used to reset a tripped drive. When in hand mode, used to stop the drive.		Control Keypad Provides access to the drive parameters, and also allows control of the drive when Hand operation is selected. Navigate Button Used to display real-time information, to access and exit parameter edit mode and to store parameter changes Up Button Used to increase speed in real-time mode or to increase parameter values in parameter edit mode Down Button Used to decrease the speed in real-time mode or to decrease parameter values in parameter edit mode.




5.6 Drive Operating Displays

01 INHIBIT 37kW 400V 3ph	01 Output Frequency H 23.7 Hz 0.3A 0.02kW	01 INHIBIT 37kW 400V 3ph	Under voltage U-Volt Press STOP key to reset
Displayed when the Safe Torque Off function is activated	Displayed when the drive power is applied, motor stopped	Drive operating, display showing output information	Drive trip display showing trip condition



5.7 Accessing and Changing Parameter Values

01 STOP 37kW 400V 3ph	Maximum speed limit P1-01 50.0Hz	Maximum speed limit 50.0 Hz P1-01 t250.0 t0.0	Maximum speed limit 23.7 Hz P1-01 t250.0 t0.0
			
Hold navigate button in for >1 sec	Use up and down keys to scroll to required parameter	Press/release navigate button when required parameter shown	Use up and down keys to edit parameter value

5.8 Changing the Language in OLED Display

	
	
Hold down the Start, Navigate and UP keys for >1s	Use the Up and Down arrows to select a language. Press the Navigate button to select.

5.9 Resetting Parameters to Factory Default Settings

LED Display		
	Press and hold the    Keys for at least 2 seconds The display will show P-dEF Press the  key	
OLED Display		
	Hold down the UP, Down, Start and Stop keys for >2 seconds	
	The display shows P-DEF Drive is returned to User Standard settings. Press the Stop key.	

5.10 Terminal Control

When delivered, the Fenner QD:Neo is in the factory default state, meaning that it is set to operate in terminal control mode and all parameters have the default values as indicated in section 6.

- Connect the drive to the supply, ensuring the correct voltage and fusing / circuit breaker protection – see section 10.4.
- Connect the motor to the drive, ensuring the correct star/delta connection for the voltage rating - see section 4.6.
- Apply the mains power to the drive, then enter the motor data from motor nameplate; P1-07 = motor rated voltage, P1-08 = motor rated current, P1-09 = motor rated frequency.
- Connect the Drive Hardware Inhibit (STO) circuit as follows (see section 4.7 for further details)
 - Link Terminal 1 to Terminals 12 (STO +)
 - Link Terminal 9 to Terminal 13 (STO -)
- Connect a control switch between the control terminals 1 and 2 ensuring that the contact is open (drive disabled).
- Connect a potentiometer (1k Ω min to 10 k Ω max) between terminals 5 and 7, and the wiper to terminal 6.
- With the potentiometer set to zero, switch on the supply to the drive. The display will show **5EOP**.
- Close the control switch, terminals 1-2. The drive is now 'enabled' and the output frequency/speed are controlled by the potentiometer. The display shows zero speed in Hz (**H 0.00**) with the potentiometer turned to minimum.
- Turn the potentiometer to maximum. The motor will accelerate to 50Hz, (60Hz for HP drives), the default value of P1-01, under the control of the acceleration ramp time P1-03.
- If the potentiometer is turned to minimum, the motor will decelerate to 0Hz, the default minimum speed set in P1-02, under the control of the deceleration ramp P1-04. The output speed can be adjusted anywhere between minimum and maximum speed using the potentiometer.
- To display motor current (Amps), briefly press the  (Navigate) key.
- Press  again to display the motor power.
- Press  again to return to speed display.
- To stop the motor, disable the drive by opening the control switch (terminals 1-2).
- If the enable/disable switch is opened the drive will decelerate to stop at which time the display will show **5EOP**.

5.11 Keypad Control

To allow the Fenner QD:Neo to be controlled from the keypad in a forward direction only, set P1-12 = 1:

- Connect the drive to the supply, ensuring the correct voltage and fusing / circuit breaker protection – see section 10.4.
- Connect the motor to the drive, ensuring the correct star/delta connection for the voltage rating - see section 4.6.
- Apply the mains power to the drive, then enter the motor data from motor nameplate; P1-07 = motor rated voltage, P1-08 = motor rated current, P1-09 = motor rated frequency.
- Connect the Drive Hardware Inhibit (STO) circuit as follows (see section 4.7 for further details)
 - Link Terminal 1 to Terminals 13 (STO +)
 - Link Terminal 9 to Terminal 12 (STO -)
- Connect a control switch between the control terminals 1 and 2 ensuring that the contact is open (drive disabled).
- Enable the drive by closing the switch between control terminals 1 & 2. The display will show 5toP.
- Press the  key. The display shows H 0.0.
- Press  to increase speed.
- The drive will run forward, increasing speed until  is released.
- Press  to decrease speed. The drive will decrease speed until  is released. The rate of deceleration is limited by the setting in P1-04.
- Press the  key. The drive will decelerate to rest at the rate set in P1-04.
- The display will finally show 5toP at which point the drive is disabled
- To preset a target speed prior to enable, press the  key whilst the drive is stopped. The display will show the target speed, use the  &  keys to adjust as required then press the key to return the display to 5toP.
- Pressing the  key will start the drive accelerating to the target speed.
- To allow the Fenner QD:Neo to be controlled from the keypad in a forward and reverse direction, set P1-12 = 2:
- Operation is the same as when P1-12=1 for start, stop and changing speed.
- Press the  key. The display changes to H 0.0.
- Press  to increase speed
- The drive will run forward, increasing speed until  is released. Acceleration is limited by the setting in P1-03. The maximum speed is the speed set in P1-01.
- To reverse the direction of rotation of the motor, press the  key again.

5.12. Operating in Sensorless Vector Speed Control Mode

Fenner QD:Neo can be programmed by the user to operate in Sensorless Vector mode, which provides enhanced low speed torque, optimum motor speed regulation regardless of load and accurate control of the motor torque. In most applications, the default Voltage Vector control mode will provide adequate performance, however if Sensorless Vector operation is required, use the following procedure.

- Ensure advanced parameter access is enabled by setting P1-14 = 101
- Enter the motor nameplate details into the relevant parameters as follows
 - P1-07 Motor Rated Voltage
 - P1-08 Motor Rated Current
 - P1-09 Motor Rated Frequency
 - (Optional) P1-10 Motor Rated Speed (Rpm)
 - P4-05 Motor Power Factor
- Select Sensorless Vector control mode by setting P4-01 = 0
- Ensure that the motor is correctly connected to the drive



The Autotune will begin immediately when P4-02 is set regardless of the status of the drive enable signal. Whilst the autotune procedure does not drive or spin the motor, the motor shaft may still turn slightly. It is not normally necessary to uncouple the load from the motor; however the user should ensure that no risk arises from the possible movement of the motor shaft

It is essential that the correct motor data is entered into the relevant drive parameters. Incorrect parameter settings can result in poor or even dangerous performance.

6.0 Parameters

6.1 Parameter Set Overview

The Fenner QD:Neo set consists of 6 groups as follows:

- Group 0 - Read only monitoring parameters
- Group 1 - Basic configuration parameters
- Group 2 - Extended parameters
- Group 3 - PID control parameters
- Group 4 - High performance motor control parameters
- Group 5 - Field bus parameters

When the Fenner QD:Neo is reset to factory defaults, or is in its factory supplied state, only Group 1 parameters can be accessed. In order to allow access to parameters from the higher level groups, P1-14 must be set to the same value as P2-40 (default setting = 101). With this setting the parameter groups 1-5 can be accessed, along with the first 38 parameters in Group 0.

6.2 Parameter Group 1 - Basic Parameters

Par	Parameter Name	Minimum	Maximum	Default	Units
P1-01	Maximum Frequency / Speed Limit	P1-02	500.00	50.0 (60.0)	Hz/rpm
	Maximum output frequency or motor speed limit - Hz or rpm. If P1-10>0, the value entered/displayed is in rpm				
P1-02	Minimum Frequency / Speed Limit	0.0	P1-01	0.0	Hz/rpm
	Minimum speed limit - Hz or rpm If P1-10>0, the value entered/displayed is in rpm				
P1-03	Acceleration Ramp Time	See below		5.0	Seconds
	Acceleration ramp time from 0 to base speed (P1-09) in seconds				
P1-04	Deceleration Ramp Time	See Below		5.0	Seconds
	Deceleration ramp time from base speed (P1-09) to standstill in seconds. When set to zero, fastest possible ramp time without trip is activated.				
P1-05	Stop Mode	0	3	0	-
	0 : Ramp to Stop. When the enable signal is removed, the drive will ramp to stop, with the rate controlled by P1-04 as described above. In this mode, the drive brake transistor (where fitted) is disabled. 1 : Coast to stop. When the enable signal is removed, the drive output is immediately disabled, and the motor will coast (free wheel) to stop. If the load can continue to rotate due to inertia, and the drive may possibly be re-enabled whilst the motor is still rotating, the spin start function (P2-26) should be enabled. In this mode, the drive brake transistor (where fitted) is disabled. 2 : Ramp to Stop. When the enable signal is removed, the drive will ramp to stop, with the rate controlled by P1-04 as described above. The Fenner QD brake chopper is also enabled in this mode. 3 : Coast to Stop. When the enable signal is removed, the drive output is immediately disabled, and the motor will coast (freewheel) to stop. If the load can continue to rotate due to inertia, and the drive may possibly be re-enabled whilst the motor is still rotating, the spin start function (P2-26) should be enabled. The drive brake chopper is enabled in this mode, however it will only activate when required during a change in the drive frequency setpoint, and will not activate when stopping.				
P1-06	Energy Optimiser	0	1	0	-
	Only active when enhanced V/F motor control mode is selected (P4-01=2) 0 : Disabled. 1 : Enabled. When enabled the Energy Optimiser attempts to reduce the overall energy consumed by the drive and motor when operating at constant speeds and light loads. The output voltage applied to the motor is reduced. The Energy Optimiser is intended for applications where the drive may operate for some periods of time with constant speed and light motor load, whether constant or variable torque.				
P1-07	Motor Rated Voltage	Drive Rating Dependent			Volts
	This parameter should be set to the rated (nameplate) voltage of the motor (Volts)				
P1-08	Motor Rated Current	Drive Rating Dependent			Volts
	This parameter should be set to the rated (nameplate) current of the motor				
P1-09	Motor Rated Frequency	25	500	50 (60)	Hz
	This parameter should be set to the rated (nameplate) frequency of the motor				
P1-10	Motor Rated Speed	0	30000	0	rpm
	This parameter can be optionally set to the rated (nameplate) rpm of the motor. When set to the default value of zero, all speed related parameters are displayed in Hz, and the slip compensation for the motor is disabled. Entering the value from the motor nameplate enables the slip compensation function, and the Fenner QD Neo display will now show motor speed in estimated rpm. All speed related parameters, such as minimum and maximum speed, preset speeds etc., will also be displayed in rpm. Note: When the drive is operated with the optional encoder feedback interface, this parameter must be set to the correct nameplate rpm of the connected motor.				

P1-11	V/F Mode Voltage Boost	0.0	Drive Rating Dependent	%	
	Voltage boost is used to oncrease the applied motor voltage at low output frequencies, in order to improve low speed and starting torque. Excessive voltage boost levels may result in increased motor current and temperature, and force ventilation of the motor may be required. An automatic setting (<i>Auto</i>) is also possible, whereby the Fenner QD:Neo will automatically adjust this parameter based on the motor parameters measured during an autotune.				
P1-12	Primary Command Source Mode	0	6	0	-
	0: Terminal Control. The drive responds directly to the signals applied to the control terminals. 1 : Uni-directional Keypad Control. The drive can be controlled in the forward direction only using an external or remote keypad 2 : Bi-Directional Keypad Control. The drive can be controlled in the forward and reverse directions using an external or remote keypad. Pressing the keypad START button toggles between forward and reverse. 3 : PI Control. The output frequency is controlled by the internal PID controller 4 : Fieldbus Control. Control via Modbus RTU if no fieldbus interface option is present, otherwise control is from the fieldbus option module interface. 5 : Slave Mode. The drive acts as a slave to a connected Fenner QD:Neo operating in master mode 6 : CAN bus Control. Control via CAN bus connected to the RJ45 serial interface connector.				
P1-13	Digital Inputs Function Select	0	21	1	-
	Defines the function of the digital inputs depending on the control mode setting in P1-12. See section 7.1 for more information.				
P1-14	Extended Menu Access Code	0	30000	0	-
	Parameter access control. The following settings are applicable: P1-14 = P2-40 = 101 Allows access to Parameter Groups 0-5				

7. Digital Input Functions

7.1 Digital Input Configuration Parameter P1-13

P1-13	Digital Input 1 (Terminal 2)	Digital Input 2 (Terminal 3)	Digital Input 3 (Terminal 4)	Analog Input 1 (Terminal 6)	Analog Input 2 (Terminal 10)
0	User defined	User defined	User defined	User defined	User defined
1	O : Stop C : Run	O : Forward C : Reverse	O : Selected speed Ref C : Preset speed 1, 2	Analog 1 speed reference	O : Preset speed 1 C : Preset speed 2
2	O : Stop C : Run	O : Forward C : Reverse	Digital Input 3	Analog Input 1	Analog Input 2
			Off	Off	Off
			On	Off	Off
			Off	On	Off
			On	On	Off
			Off	Off	On
			On	Off	On
			Off	On	On
3	O : Stop C : Run	O : Forward C : Reverse	O : Selected speed ref C : Preset speed 1	Analog 1 speed reference	Analog torque reference
4	O : Stop C : Run	O : Forward C : Reverse	O : Selected speed ref C : Preset speed 1	Analog 1 speed reference	O : Decel ramp 1 (P1-04) C : Decel ramp 2 (P2-25)
5	O : Stop C : Run	O : Forward C : Reverse	O : Selected speed ref C : Analog input 2	Analog 1 speed reference	Analog 2 speed reference
6	O : Stop C : Run	O : Forward C : Reverse	O : Selected speed ref C : Preset speed 1	Analog 1 speed reference	External trip* O : trip C : Run
7	O : Stop C : Run	O : Forward C : Reverse	Digital Input 3	Analog Input 1	Preset Speed
			Off	Off	Preset speed 1
			On	Off	Preset speed 2
			Off	On	Preset speed 3
			On	On	Preset speed 4
8	O : Stop C : Run	O : Forward C : Reverse	Digital Input 3	Analog Input 1	Preset Speed
			Off	Off	Preset speed 1
			On	Off	Preset speed 2
			Off	On	Preset speed 3
			On	On	Preset speed 4
9	O : Stop C : Run	O : Forward C : Reverse	Digital Input 3	Analog Input 1	Preset Speed
			Off	Off	Preset speed 1
			On	Off	Preset speed 2
			Off	On	Preset speed 3
			On	On	Preset speed 4
10	O : Stop C : Run	O : Forward C : Reverse	Normally Open (N.O.) Close to increase speed	Normally Open (N.O.) Close to reduce speed	O : Selected speed ref C : Preset speed 1
11	O : Stop C : Run Fwd	O : Stop C : Run Rev	O : Selected speed ref C : Preset speed 1,2	Analog 1 speed reference	O : Preset speed 1 C : Preset speed 2
12	O : Stop C : Run Fwd	O : Stop C : Run Rev	Digital Input 3	Analog Input 1	Analog Input 2
			Off	Off	Off
			On	Off	Off
			Off	On	Off
			On	On	Off
			Off	Off	On
			On	Off	On
			Off	On	On
			On	On	On
13	O : Stop C : Run Fwd	O : Stop C : Run Rev	O : Selected speed Ref C : Preset speed 1	Analog 1 speed reference	Analog torque reference
14	O : Stop C : Run Fwd	O : Stop C : Run Rev	O : Selected speed ref C : Preset speed 1	Analog 1 speed reference	O : Decel ramp 1 (P1-04) C : Decel ramp 2 (P2-25)
15	O : Stop C : Run Fwd	O : Stop C : Run Rev	O : Selected speed ref C : Analog input 2	Analog 1 speed reference	Analog 2 speed reference
16	O : Stop C : Run Fwd	O : Stop C : Run Rev	O : Selected speed ref C : Preset speed 1	Analog 1 speed reference	External trip* O : trip C : Run

17	O : Stop C : Run Fwd	O : Stop C : Run Rev	Digital Input 3 Off On Off On	Analog Input 1 Off Off On On	Preset Speed Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4	External trip* O : trip C : run
18	O : Stop C : Run Fwd	O : Stop C : Run Rev	Digital Input 3 Off On Off On	Analog Input 1 Off Off On On	Preset Speed Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4	O : Decel ramp 1 (P1-04) C : Decel ramp 2 (P2-25)
19	O : Stop C : Run Fwd	O : Stop C : Run Rev	Digital Input 3 Off On Off On	Analog Input 1 Off Off On On	Preset Speed Preset speed 1 Preset speed 2 Preset speed 3 Preset speed 4	O : Selected speed ref C : Preset speed 1 ..4
20	O : Stop C : Run Fwd	O : Stop C : Run Rev	Normally Open (N.O.) Close to increase speed	Normally Open (N.O.) Close to reduce speed		O : Selected speed ref C : Preset speed 1
21	Normally Open (N.O.) Close to run Fwd	Normally Closed (N.C.) Open to stop	Normally Open (N.O.) Close to run Rev	Analog 1 speed reference		O : Selected speed ref C : Preset speed 1

The selected speed reference referred to in the above table is determined by the value set in P1-12 (Control Mode):

P1-12 (Control Mode)	Selected Speed Reference
0 : Terminal mode	Analog input 1
1 : Keypad Mode (uni-directional)	Digital Potentiometer
2 : Keypad Mode (bi-directional)	Digital Potentiometer
3 : User PID mode	PID controller output
4 : Fieldbus Control	Speed reference via Fieldbus
5 : Slave Mode	Speed reference via Optibus

*Note: If a motor thermistor is to be connectd, this must be selected in P2-33.

8. Extended Parameters

8.1 Parameter Group 2 - Extended Parameters

Par	Parameter Name	Minimum	Maximum	Default	Units
P2-01	Preset / Jog Frequency / Speed 1	P1-02	P1-01	5.0	Hz/rpm
P2-02	Preset / Jog Frequency / Speed 2	P1-02	P1-01	10.0	Hz/rpm
P2-03	Preset / Jog Frequency / Speed 3	P1-02	P1-01	25.0	Hz/rpm
P2-04	Preset / Jog Frequency / Speed 4	P1-02	P1-01	50.0 (60.0)	Hz/rpm
P2 -05	Preset / Jog Frequency / Speed 5	P1-02	P1-01	0.0	Hz/rpm
P2-06	Preset / Jog Frequency / Speed 6	P1-02	P1-01	0.0	Hz/rpm
P2-07	Preset / Jog Frequency / Speed 7	P1-02	P1-01	0.0	Hz/rpm
P2-08	Preset / Jog Frequency / Speed 8	P1-02	P1-01	0.0	Hz/rpm
Preset speeds / frequencies selected by digital inputs depending on the setting of P1-13 If P1-10 =), the values are entered as Hz. If P1-10 > 0, the values are entered as rpm. Setting a negative value will reverse the direction of the motor rotation					
P2-09	Skip Frequency Centre Point	P1-02	P1-01	0.0	Hz/rpm
P2-10	Skip Frequency Band Width	0.0	P1-01	0.0	Hz/rpm
The skip frequency function is used to avoid the Fenner QD:Neo operating at a certain output frequency, for example at a frequency which causes mechanical resonance in a particular machine. Parameter P2-09 defines the centre point of the skip frequency band, and is used in conjunction with P2-10. The Fenner QD:Neo output frequency will ramp through the defined band at the rates set in P1-03 and P1-04 respectively, and will not hold any output frequency within the defined band. If the frequency reference applied to the drive is within the band, the Fenner QD:Neo output frequency will remain at the upper or lower limit of the band.					
P2-11	Analog Output 1 (Terminal 8) Function Select	0	11	8	-
Digital Output Mode. Logic 1 = +24V DC 0 : Drive Enabled (Running). Logic 1 when the Fenner QD:Neo is enabled (running) 1 : Drive Healthy. Logic 1 when no fault condition exists on the drive 2 : At Target Frequency (Speed). Logic 1 when the output frequency matches the setpoint frequency 3 : Output Frequency > 0.0. Logic 1 when the motor runs above zero speed 4 : Output Frequency >+ Limit. Logic 1 when the motor speeds exceeds the adjustable limit 5 : Output Current >+ Limit. Logic 1 when the motor current exceeds the adjustable limit 6 : Motor Torque >=Limit. Logic when the motor torque exceeds the adjustable limit 7 : Analog Input 2 Signal Level >= Limit. Logic when the signal applied to the analog input 2 exceeds the adjustable limit Note: When using settings 4-7, parameters P2-16 and P2-17 must be used together to control the behaviour. The output will switch to Logic 1 when the selected signal exceeds the value programmed in P2-16, and return to Logic 0 when the signal falls below the value programmed in P2-17. Analog Output Mode 8 : Output Frequency (Motor Speed) 0 to P-01 9 : Output (Motor) Current. 0 to 200% of P1-08 10 : Motor Torque. 0 to 200% of motor rated torque 11: Output (Motor) Power. 0 to 150% of drive read power					
P2-12	Analog Output 1 (Terminal 8) Format	See Below		U 0- 10	-
U 0- 10 = 0 to 10V U 10-0 = 10 to 0V A 0-20 + 0 to 20mA A 20-0 = 20 to 0mA A 4-20 = 4 to 20mA A 20-4 = 20 to 4mA					
P2-13	Analog Output 2 (Terminal 11) Function Select	0	11	9	-
Digital Output Mode. Logic 1 = +24V DC 0 : Drive Enabled (Running). Logic 1 when the Fenner QD:Neo is enabled (running) 1 : Drive Healthy. Logic 1 when no fault condition exists on the drive 2 : At Target Frequency (Speed). Logic 1 when the output frequency matches the setpoint frequency 3 : Output Frequency > 0.0. Logic 1 when the motor runs above zero speed					

	4 : Output Frequency >= Limit. Logic 1 when the motor speed exceeds the adjustable limit 5 : Output Current >= Limit. Logic 1 when the motor current exceeds the adjustable limit 6 : Output Torque >= Limit. Logic when the motor torque exceeds the adjustable limit 7 : Analog Input 2 Signal Level >= Limit. Logic when the signal applied to the Analog Input 2 exceeds the adjustable limit. Note: When using settings 4-7, parameters P2-16 and P2-17 must be used together to control the behaviour. The output will switch to Logic 1 when the selected signal exceeds the value programmed in P2-16, and return to Logic 0 when the signal falls below the value programmed in P2-17. Analog Output Mode 8 : Output Frequency (Motor Speed). 0 to P-01 9 : Output (Motor) Current. 0 to 200% of P1-08 10 : Output (Motor) Power. 0 to 150% of drive rated power 11 : Output (Motor) Power. 0 to 150% of drive rated power				
P2-14	Analog Output 2 (Terminal 11) Format	See Below	U 0-10		
	U 0-10 = 0 to 10V U 10-0 = 10 to 0V A 0-20 = 0 to 20mA A 20-0 = 20 to 0mA A 4-20 = 4 to 20mA A 20-4 = 20 to 4mA				
P2-15	User Relay 1 Output (Terminals 14, 15 & 16) Function Select	0	7	1	-
	Selects the function assigned to Relay Output 1. The relay has three output terminals, Logic 1 indicates the relay is active, and therefore terminals 14 and 15 will be linked together. 0 : Drive Enabled (Running). Logic 1 when the motor is enabled 1 : Drive Healthy. Logic 1 when power is applied to the drive no fault exists 2 : At Target Frequency (Speed). Logic 1 when the output frequency matches the setpoint frequency 3 : Output Frequency > 0.0Hz. Logic 1 when the drive output frequency to the motor exceeds 0.0Hz 4 : Output Frequency >= Limit. Logic 1 when the motor speed exceeds the adjustable limit 5 : Output Current >= Limit. Logic 1 when the motor current exceeds the adjustable limit 6 : Output Torque >= Limit. Logic 1 when the motor torque exceeds the adjustable limit 7 : Analog Input 2 Signal Level >= Limit. 1 Logic when the signal applied to the Analog Input 2 exceeds the adjustable limit Note: When using signals 4-7, parameters P2-16 and P2-17 must be used together to control the behaviour. The output will switch to Logic 1 when the selected signal exceeds the value programmed in P2-16, and return to Logic 0 when the signal falls below the value programmed in P2-17.				
P2-16	Adjustable Threshold 1 Upper Limit (Analog Output 1/Relay Output 1)	P2-17	200.0	100.0	%
P2-17	Adjustable Threshold 1 Lower Limit (Analog Output 1/Relay Output 1)	0.0	P2-16	0.0	%
	Used in conjunction with some settings of Parameters P2-11 & P2-15				
P2-18	User Relay 2 Output (Terminals 17 & 18) Function Select	0	8	0	-
	Selects the function assigned to Relay Output 2. The relay has two output terminals. Logic 1 indicates the relay is active, and therefore terminals 17 and 18 will be linked together 0 : Drive Enabled (Running). Logic 1 when the motor is enabled 1 : Drive Healthy. Logic 1 when power is applied to the drive and no fault exists 2 : At Target Frequency (Speed). Logic 1 when the output frequency matches the setpoint frequency 3 : Output Frequency > 0.0Hz. Logic 1 when the drive output frequency to the motor exceeds 0.0Hz 4 : Output Frequency >= Limit. Logic 1 when the motor speed exceeds the adjustable limit 5 : Output Current >= Limit. Logic 1 when the motor current exceeds the adjustable limit 6 : Output Torque >= Limit. Logic 1 when the motor torque exceeds the adjustable limit 7 : Analog Input 2 Signal Level >= Limit. 1 Logic when the signal applied to the Analog Input 2 exceeds the adjustable limit 8 : Hoist Brake Control. The relay can be used to control the motor holding brake on a hoist. Contact your local Fenner Authorised Distributor for further information on this feature. Note: When using settings 4-7, parameters P2-19 and P2-20 must be used together to control the behaviour. The output will switch to Logic 1 when the selected signal exceeds the value programmed in P2-19, and return to Logic 0 when the signal falls below the value programmed in P2-20				
P2-19	Adjustable Threshold 1 Upper Limit (Analog Output 2/Relay Output 2)	P2-20	200.0	100.0	%
P2-20	Adjustable Threshold 1 Lower Limit (Analog Output 2/Relay Output 2)	0.0	P2-19	0.0	%
	Used in conjunction with some settings of Parameters P2-13 & P2-18				
P2-21	Display Scaling Factor	-30.000	30.000	0.000	-

P2-22	Display Scaling Source	0	2	0	-
	P2-21 & P2-22 allow the user the program the Fenner QD:Neo to display an alternative output unit scaled from an existing parameter, e.g. to display conveyor speed in metres per second based on the output frequency. This function is disabled if P2-21 is set to 0. If P2-21 is set >0, the variable selected in P2-22 is multiplied by the factor entered in P2-21 and displayed whilst the drive is running with a 'c' to indicate the customer scaled units. P2-22 Options 0 : Motor Speed 1 : Motor Current 2 : Analog Input 2				
P2-23	Zero Speed Holding Time	0.0	60.0	0.2	Seconds
	Determines the time for which the drive output frequency is held at zero when stopping, before the drive output is disabled.				
P2-24	Effective Switching Frequency	Drive Rating Dependent			kHz
	Effective power stage switching frequency. The range of settings available and factory default parameter setting depend on the drive power and voltage rating. Higher frequencies reduce the audible 'ringing' noise from the motor, and improve the output current waveform, at the expense of increased drive losses.				
P2-25	2nd Declaration Ramp Time	0.00	30.0	0.00	Seconds
	This parameter allows an alternative declaration ramp down time to be programmed into Fenner QD:Neo, which can be selected by digital inputs (dependent on the setting of P1-13) or selected automatically in the case of a mains power loss if P2-38=2. When set to 0.0, the drive will coast to stop.				
P2-26	Spin Start Enable	0	1	0	-
	0: Disabled. 1 : Enabled. When enabled, on start up the drive will attempt to determine if the motor is already rotating, and will begin to control the motor from its current speed. A short delay may be observed when starting motors are not turning.				
P2-27	StandbyTimer Mode	0.0	250.0	0.0	Seconds
	This parameter defines time period, whereby if the drive operates at minimum speed for at least the set time period, the Fenner QD:Neo output will be disabled, and the display will show <i>Standby</i> . The Function is disabled if P2-27 =0.0				
P2-28	Slave Speed Scaling Control	0	3	0	-
	Active in Keypad mode (P1-12 = 1 or 2) and slave mode (P1-12=5) only. The keypad reference can be multiplied by a preset scaling factor or adjusted using an analog trim or offset. 0 : Disabled. No scaling or offset is applied. 1 : Actual Speed = Digital Speed x P2-29 2 : Actual Speed = (Digital Speed x P2-29) + Analog Input 1 Reference 3 : Actual Speed = (Digital Speed x P2-29) x Analog Input 1 Reference				
P2-29	Slave Speed Scaling Factor	-500.0	500.0	100.0	%
	Used in conjunction with P2-28				
P2-30	Analog Input 1 (Terminal 6) Format	See Below			-
	U 0- 10 = 0 to 10 Volt Signal (Uni-polar) U 10- 0 = 10 to 0 Volt Signal (Uni-polar) - 10- 10 = -10 to +10 Volt Signal (Bi-polar) A 0- 20 = 0 to 20mA Signal E 4- 20 = 4 to 20mA Signal, the Fenner QD: Neo drive will trip and show the fault code 4- 20F if the signal level; falls below 3mA r 4- 20 = 4 to 20mA Signal, the Fenner QD:Neo will ramp to stop if the signal level falls below 3mA E 20- 4 = 20 to 4mA Signal, the Fenner QD: Neo will trip and show the fault code 4- 20F if the signal level falls below 3mA r 20- 4 = 20 to 4mA Signal, the Fenner QD:Neo will ramp to stop if the signal level falls below 3mA				
P2-31	Analog Input 1 Scaling	0.0	500.0	100.0	%
	Scales the analog input by this factor, e.g. if P2-30 is set for 0-10V, and the scaling factor is set to 200.0%, a 5 volt input will result in the drive running at maximum speed (P1-01)				
P2-32	Analog Input 1 Offset	-500.0	500.0	0.0	%
	Set an offset, as a percentage of the fulls cale range of the input, which is applied to the analog input signal.				

P2-33	Analog Input 2 (Terminal 10) Format	See Below	U 0-10	-	
	U 0-10 = 0 to 10 Volt Signal (Uni-polar) U 10-0 = 10 to 0 Volt Signal (Uni-polar) Ptc-th = Motor PTC Thermistor Input R 0-20 = 0 to 20mA Signal				
	L 4-20 = 4 to 20mA Signal, the Fenner QD:Neo will trip and show the fault code 4-20F if the signal level falls below 3mA r 4-20 = 4 to 20mA Signal, the Fenner QD:Neo will ramp to stop if the signal level falls below 3mA L 20-4 = 20 to 4mA Signal, the Fenner QD:Neo will trip and show the fault code 4-20F if the signal level falls below 3mA r 20-4 = 20 to 4mA Signal, the Fenner QD:Neo will ramp to stop if the signal level falls below 3mA				
P2-34	Analog Input 2 Scaling	0.0	500.0	100.0	%
	Scales the analog input by this factor, e.g. if P2-30 is set for 0-10V, and the scaling factor is set to 200.0%, a 5 volt input will result in the drive running at maximum speed (P1-01)				
P2-35	Analog Input 2 Offset	-500.0	500.0	0.0	%
	Sets an offset, as a percentage of the full scale range of the input, which is applied to the analog input signal.				
P2-36	Start Mode Select / Automatic Restart	See below	Auto-0	-	
	Defines the behaviour of the drive relating to the enable digital input and also configures the Automatic Restart function. Ed9E-r : Following Power on or reset, the drive will not start if Digital Input 1 remains closed. The Input must be closed after a power on or reset to start the drive. Auto-0 : Following a Power On or Reset, the drive will automatically start if Digital Input 1 is closed. Auto-1 to Auto-5 : Following a trip, the drive will make up to 5 attempts to restart at 20 second intervals. The drive must be powered down to reset the counter. The numbers of restart attempts are counted, and if the drive fails to start on the final attempt, the drive will fault with, and will require the user to manually reset the fault.				
P2-37	Keypad Mode Restart Speed	0	3	1	-
	This parameter is only active when P1-12 = 1 or 2. When settings 0 to 3 are used, the drive must be started by pressing the Start key on the keypad. When settings 4 – 7 are used, the drive starting is controlled by the enable digital input. 0 : Minimum Speed. Following a stop and restart, the drive will always initially run at the minimum speed P1-02 1 : Previous Operating Speed. Following a stop and restart, the drive will return to the last keypad setpoint speed used prior to stopping 2 : Current Running Speed. Where the Fenner QD:Neo is configured for multiple speed references (typically Hand / Auto control or Local / Remote control), when switched to keypad mode by a digital input, the drive will continue to operate at the last operating speed 3 : Preset Speed 8. Following a stop and restart, the Fenner QD:Neo will always initially run at Preset Speed 8 (P2-08) 4 : Minimum Speed (Terminal Enable). Following a stop and restart, the drive will always initially run at the minimum speed P1-02 5 : Previous Operating Speed (Terminal Enable). Following a stop and restart, the drive will return to the last keypad setpoint speed used prior to stopping 6 : Current Running Speed (Terminal Enable). Where the Fenner QD:Neo is configured for multiple speed references (typically Hand / Auto control or Local / Remote control), when switched to keypad mode by a digital input, the drive will continue to operate at the last operating speed 7 : Preset Speed 8 (Terminal Enable). Following a stop and restart, the Fenner QD:Neo will always initially run at Preset Speed 8 (P2-08)				
P2-38	Main Loss Ride Through / Stop Control	0	2	0	-
	Controls the behaviour of the drive in response to a loss of mains power supply whilst the drive is enabled. 0: Mains Loss Ride Through. The Fenner QD:Neo will attempt to continue operating by recovering energy from the load motor. Providing that the mains loss period is short, and sufficient energy can be recovered before the drive control electronics power off, the drive will automatically restart on return of mains power 1: Coast To Stop. The Fenner QD:Neo will immediately disable the output to the motor, allowing the load to coast or free wheel. When using this setting with high inertia loads, the Spin Start function (P2-26) may need to be enabled 2: Fast Ramp To Stop. The drive will ramp to stop at the rate programmed in the 2nd deceleration time P2-25				
P2-39	Parameter Access Lock	0	1	0	-
	0 : Unlocked. All parameters can be accessed and changed 1 : Locked. Parameter values can be displayed, but cannot be changed				
P2-40	Extended Parameter Access Code Definition	0	9999	101	-
	Defines the access code which must be entered in P1-14 to access parameter groups above Group 1				

8.2 Parameter Group 3 - PID Control

Par	Parameter Name	Minimum	Maximum	Default	Units
P3-01	PID Proportional Gain	0.1	30.0	1.0	-
	PID Controller Proportional Gain. Higher values provide a greater change in the drive output frequency in response to small changes in the feedback signal. Too high a value can cause instability				
P3-02	PID Integral Time Constant	0.0	30.0	1.0	s
	PID Controller Integral Time. Larger values provide a more damped response for systems where the overall process responds slowly				
P3-03	PID Differential Time Constant	0.00	1.00	0.00	s
	PID Differential Time Constant				
P3-04	PID Operating Mode	0	1	0	-
	0 : Direct Operation. Use this mode if an increase in the motor speed should result in an increase in the feedback signal 1 : Inverse Operation. Use this mode if an increase in the motor speed should result in a decrease in the feedback signal				
P3-05	PID Reference (Setpoint) Source Select	0	2	0	-
	Selects the source for the PID Reference / Setpoint 0 : Digital Preset Setpoint. P3-06 is used 1 : Analog Input 1 Setpoint 2 : Analog Input 2 Setpoint				
P3-06	PID Digital Reference (Setpoint)	0.0	100.0	0.0	%
	When P3-05 = 0, this parameter sets the preset digital reference (setpoint) used for the PID Controller				
P3-07	PID Controller Output Upper Limit	P3-08	100.0	100.0	%
	Limits the maximum value output from the PID controller				
P3-08	PID Controller Output Lower Limit	0.0	P3-07	0.0	%
	Limits the minimum output from the PID controller				
P3-09	PID Output Limit Control	0	3	0	-
	0 : Digital Output Limits. The output range of the PID controller is limited by the values of P3-07 & P3-08 1 : Analog Input 1 Provides a Variable Upper Limit. The output range of the PID controller is limited by the values of P3-08 & the signal applied to Analog Input 1 2 : Analog Input 1 Provides a Variable Lower Limit. The output range of the PID controller is limited by the signal applied to Analog Input 1 & the value of P3-07 3 : PID output Added to Analog Input 1 Value. The output value from the PID Controller is added to the speed reference applied to the Analog Input 1				
P3-10	PID Feedback Signal Source Select	0	1	0	-
	0 : Analog Input 2 1 : Analog Input 1				
P3-11	Minimum PID Error to Enable Ramps	0.0	25.0	0.0	%
	Defines a threshold PID error level, whereby if the difference between the setpoint and feedback values is less than the set threshold, the internal ramp times of the drive are disabled. Where a greater PID error exists, the ramp times are enabled to limit the rate of change of motor speed on large PID errors, and react quickly to small errors. Setting to 0.0 means that the drive ramps are always enabled. This parameter is intended to allow the user to disable the drive internal ramps where a fast reaction to the PID control is required, however by only disabling the ramps when a small PID error exists, the risk of possible over current or over voltage trips being generated are reduced.				
P3-12	PID Feedback Value Display Scaling Factor	0.000	50.000	0.000	-
	Applies a scaling factor to the displayed PID feedback, allowing the user to display the actual signal level from a transducer, e.g. 0 – 10 Bar etc.				
P3-13	PID Feedback Wake Up Level	0.0	100.0	0.0	%
	Sets a programmable level whereby if the drive enters standby motor whilst operating under PID control, the selected feedback signal must fall below this threshold before the drive will return to normal operation.				
P3-14	Reserved Parameter	-	-	-	-
	No function				

8.3 Parameter Group 4 - High Performance Motor Control

	Incorrect adjustment of parameters in menu group 4 can cause unexpected behaviour of the motor and any connected machinery. It is recommended that these parameters are only adjusted by experienced users.				
Par	Parameter Name	Minimum	Maximum	Default	Units
P4-01	Motor Control Mode	0	2	2	-
	Selects the motor control method. An autotune must be performed if setting 0 or 1 is used. 0: Speed Control with Torque Limit (vector) 1: Torque Control with Speed Limit (vector) 2: Speed Control (Enhanced V/F)				
P4-02	Motor Parameter Auto-tune Enable	0	1	0	-
	When set to 1, the drive immediately carries out a non-rotating autotune to measure the motor parameters for optimum control and efficiency. Following completion of the autotune, the parameter automatically returns to 0.				
P4-03	Vector Speed Controller Proportional Gain	0.1	400.0	25.0	%
	Sets the proportional gain value for the speed controller when operating in Vector Speed or Vector Torque motor control modes (P4-01 = 0 or 1). Higher values provide better output frequency regulation and response. Too high a value can cause instability or even over current trips. For applications requiring best possible performance, the value should be adjusted to suit the connected load by gradually increasing the value and monitoring the actual output speed of the load until the required dynamic behaviour is achieved with little or no overshoot where the output speed exceeds the setpoint. In general, higher friction loads can tolerate higher values of proportional gain, and high inertia, low friction loads may require the gain to be reduced.				
P4-04	Vector Speed Controller Integral Time Constant	0.000	1.000	0.050	s
	Sets the integral time for the speed controller. Smaller values provide a faster response in reaction to motor load changes, at the risk of introducing instability. For best dynamic performance, the value should be adjusted to suit the connected load.				
P4-05	Motor Power Factor Cos ϕ	0.50	0.99	-	-
	When operating in Vector Speed or Vector Torque motor control modes, this parameter must be set to the motor nameplate power factor				
P4-06	Torque Control Reference / Limit Source	0	5	0	-
	When P4-01 = 0, this parameter defines the source for the maximum output torque limit. When P4-01 = 1, this parameter defines the source for the torque reference (setpoint). 0: Fixed Digital. The torque controller reference / limit is set in P4-07 1: Analog Input 1. The output torque is controlled based on the signal applied to Analog Input 1, whereby 100% input signal level will result in the drive output torque being limited by the value set in P4-07. 2: Analog Input 2. The output torque is controlled based on the signal applied to Analog Input 2, whereby 100% input signal level will result in the drive output torque being limited by the value set in P4-07. 3: Fieldbus. The output torque is controlled based on the signal from the communications Fieldbus, whereby 100% input signal level will result in the drive output torque being limited by the value set in P4-07. 4: Master / Slave. The output torque is controlled based on the signal from the Fenner Master / Slave, whereby 100% input signal level will result in the drive output torque being limited by the value set in P4-07. 5: PID Controller Output. The output torque is controlled based on the output of the PID controller, whereby 100% input signal level will result in the drive output torque being limited by the value set in P4-07.				
P4-07	Maximum Motoring Torque Limit	P4-08	500.0	200.0	%
	When operating in Vector Speed or Vector Torque motor control modes (P4-01 = 0 or 1), this parameter defines the maximum torque limit or reference used by the drive in conjunction with P4-06.				
P4-08	Minimum Motoring Torque Limit	0.0	P4-07	0.0	%
	Active only in Vector Speed or Vector Torque motor control modes (P4-01 = 0 or 1). Sets a minimum torque limit, whereby the when the Fenner QD: Neo is enabled, it will always attempt to maintain this torque on the motor at all times whilst operating				
	NOTE: This parameter should be used with extreme care, as the drive output frequency will increase to achieve the torque level, and may exceed the selected speed reference				
P4-09	Generator Mode Max. Torque Limit (Maximum Regenerative Torque)	0.0	200.0	200.0	%
	Active only in Vector Speed or Vector Torque motor control modes (P4-01 = 0 or 1). Sets the maximum regenerating torque allowed by the Fenner QD: Neo				
P4-10	V/F Characteristic Adjustment Frequency	0.0	P1-09	0.0	Hz
	When operating in V/F mode (P4-01 = 2), this parameter in conjunction with P4-11 sets a frequency point at which the voltage set in P4-11 is applied to the motor. Care must be taken to avoid overheating and damaging the motor when using this feature.				
P4-11	V/F Characteristic Adjustment Voltage	0	P1-07	0	V
	Used in conjunction with parameter P4-10				
P4-12	Reserved Parameter	-	-	-	-
	No Function				

8.4 Parameter Group 5 - Communication Parameters

Par	Parameter Name	Minimum	Maximum	Default	Units
P5-01	Drive Fieldbus Address	0	63	1	-
	Sets the fieldbus address for the Fenner QD:Neo				
P5-02	CAN Open Baud Rate	125	1000	500	kbps
	Sets the baud rate when CAN Open communications are used				
P5-03	Modbus RTU Baud Rate	9.6	115.2	115.2	kbps
	Sets the baud rate when CAN Open communications are used				
P5-04	Modbus Data Format	-	-	n-1	-
	Sets the expected Modbus telegram data format as follows n- 1 : No Parity, 1 stop bit n- 2 : No parity, 2 stop bits O- 1 : Odd parity, 1 stop bit E- 1 : Even parity, 1 stop bit				
P5-05	Communications Loss Timeout	0.0	5.0	1.0	%
	Sets the watchdog time period for the communications channel. If a valid telegram is not received by the Fenner QD:Neo within this time period, the drive will assume a loss of communications has occurred and react as selected below				
P5-06	Communication Loss Action	0	3	0	-
	Controls the behaviour of the drive following a loss of communications as determined by the above parameter setting. 0: Trip & Coast To Stop 1: Ramp to Stop Then Trip 2: Ramp to Stop Only (No Trip) 3: Run at Preset Speed 8				
P5-07	Fieldbus Ramp Control	0	1	0	-
	Selects whether the acceleration and deceleration ramps are control directly via the Fieldbus, or by internal drive parameters P1-03 and P1-04. 0 : Disabled. Ramps are control from internal drive parameters 1 : Enabled. Ramps are controlled directly by the Fieldbus				
P5-08	Fieldbus Process Data Word 4 Output Select	0	4	0	-
	When using an optional fieldbus interface, this parameter configures the parameter source for the 4th process data word transferred from the drive to the network master during cyclic communications 0 : Output Torque – 0 to 2000 = 0 to 200.0% 1 : Output Power – Output power in kW to two decimal places, e.g. 400 = 4.00kW 2 : Digital Input Status – Bit 0 indicates digital input 1 status, bit 1 indicates digital input 2 status etc. 3 : Analog Input 2 Signal Level – 0 to 1000 = 0 to 100.0% 4 : Drive Heatsink Temperature – 0 to 100 = 0 to 100°C				
P5-09	Reserved Parameter	-	-	-	-
	No Function				

8.5 Parameter Group 0 - Monitoring Parameters (Read Only)

Par	Description	Units
P0-01	Analog Input 1 Applied Signal Level Displays the signal level applied to analog input 1 (Terminal 6) after scaling and offsets have been applied. P0-02	%
P0-02	Analog Input 2 Applied Signal Level % Displays the signal level applied to analog input 2 (Terminal 10) after scaling and offsets have been applied.	%
P0-03	Digital Input Status Displays the status of the drive inputs, starting with the left hand side digit = Digital Input 1 etc.	-
P0-04	Pre Ramp Speed Controller Reference Displays the set point reference input applied to the drive internal speed controller	Hz
P0-05	Torque Controller Reference Displays the set point reference input applied to the drive internal torque controller	%
P0-06	Digital Speed Reference (Motorised Pot) Displays the value of the drive internal Motorised Pot (used for keypad) speed reference	Hz
P0-07	Fieldbus Communication Speed Reference Displays the setpoint being received by the drive from the currently active Fieldbus interface.	Hz
P0-08	PID Reference Setpoint Displays the setpoint input to the PID controller.	%
P0-09	PID Feedback Level Displays the Feedback input signal to the PID controller	%
P0-10	PID Controller Output Displays the output level of the PID controller	%
P0-11	Applied Motor Voltage Displays the instantaneous output voltage from the drive to the motor	V
P0-12	Output Torque Displays the instantaneous output torque level produced by the motor	%
P0-13	Trip History Log Displays the last four fault codes for the drive. Refer to section 11.1 for further information	-
P0-14	Motor Magnetising Current (Id) Displays the motor magnetising Current, providing an auto tune has been successfully completed.	A
P0-15	Motor Rotor Current Displays the motor Rotor (torque producing) current, providing an auto tune has been successfully completed.	A
P0-16	DC Bus Voltage Ripple Level Displays the level of ripple present on the DC Bus Voltage. This parameter is used by the Fenner QD:Neo for various internal protection and monitoring functions.	V
P0-17	Motor Stator Resistance (Rs) Displays the measured motor stator resistance, providing an auto tune has been successfully completed.	Ω
P0-18	Motor Stator Inductance (Ls) Displays the measured motor stator inductance, providing an auto tune has been successfully completed.	H
P0-19	Motor Rotor Resistance (Rr) Displays the measured motor rotor resistance, providing an auto tune has been successfully completed	Ohms
P0-20	DC Bus Voltage Displays the instantaneous DC Bus Voltage internally within the drive	V
P0-21	Drive Temperature Displays the Instantaneous Heatsink Temperature measured by the drive	°C
P0-22	Time Remaining to next service Displays the number of hours remaining on the service time counter before the next service is due.	V
P0-23	Operating Time Accumulated with Heatsink Temperature Above 80°C Displays the amount of time in hours and minutes that the drive has operated for during its lifetime with a heatsink temperature in excess of 80°C. This parameter is used by the drive for various internal protection and monitoring functions.	HH:MM:SS
P0-24	Operating Time Accumulated with Ambient Temperature Above 80°C Displays the amount of time in hours and minutes that the drive has operated for during its lifetime with an ambient temperature in excess of 80°C. This parameter is used by the drive for various internal protection and monitoring functions.	HH:MM:SS
P0-25	Rotor Speed (Estimated or Measured) In Vector control mode, this parameter displays either the estimated rotor speed of the motor, if no encoder feedback is present, or the measured rotor speed if an optional Encoder Feedback Interface Option is fitted.	-


Par	Description	Units
P0-26	Energy Consumption kWh Meter Displays the amount of energy consumed by the drive in kWh. When the value reaches 1000, it is reset back to 0.0, and the value of P0-27 (*MWh meter) is increased.	kWh
P0-27	Energy Consumption MWh Meter Displays the amount of energy consumed by the drive in MWh.	MWh
P0-28	Software Version and Checksum Displays the software version of the drive	-
P0-29	Drive Type Displays the type details of the drive	-
P0-30	Drive Serial Number Displays the unique serial number of the drive	-
P0-31	Drive Lifetime Operating Time Displays the total operating time of the drive. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds.	HH:MM:SS
P0-32	Drive Run Time Since Last Trip (1) Displays the total operating time of the drive since the last fault occurred. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds.	HH:MM:SS
P0-33	Drive Run Time Since Last Trip (2) Displays the total operating time of the drive since the last fault occurred. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds.	HH:MM:SS
P0-34	Drive Run Time Since Last Disable Displays the total operating time of the drive since the last Run command was received. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds.	HH:MM:SS
P0-35	Drive Internal Cooling Fan Total Operating Time Displays the total operating time of the Fenner QD:Neo internal cooling fans. The first value shown is the number of hours. Pressing the Up key will display the minutes and seconds. This is used for scheduled maintenance information	HH:MM:SS
P0-36	DC Bus Voltage Log (256ms)	V
P0-37	DC Bus Voltage Ripple Log (20ms)	V
P0-38	Heatsink Temperature Log (30ms)	°C
P0-39	Ambient Temperature Log (30ms)	°C
P0-40	Motor Current Log (256ms) The above parameters are used to store the history of various measured levels within the drive at various regular time intervals prior to a trip. The values are frozen when a fault occurs and can be used for diagnostic purposes – see section for further information.	A
P0-41	Critical Fault Counter - Over Current	-
P0-42	Critical Fault Counter - Over Voltage	-
P0-43	Critical Fault Counter - Under Voltage	-
P0-44	Critical Fault Counter - Over Temperature	-
P0-45	Critical Fault Counter - Brake Transistor Over Current	-
P0-46	Critical Fault Counter - Ambient Over Temperature These parameters contain a record of how many times certain critical faults have occurred during a drives operating lifetime. This provides useful diagnostic data	-
P0-47	Reserved Reserved parameter	-
P0-48	Reserved Reserved parameter	-
P0-49	Modbus RTU Communication Error Counter This parameter is incremented every time an error occurs on the Modbus RTU communication link. This information can be used for diagnostic purposes.	-
P0-50	CAN Open Communication Errr Counter This parameter is incremented every time an error occurs on the CAN Open communication link. This information can be used for diagnostic purposes.	-

9.0 Serial Communications

9.1 RS-485 Communications

The Fenner QD:Neo has an RJ45 connector on the front of the control panel. This connector allows the user to set up a drive network via a wired connection. The connector contains two independent RS485 connections, one for Fenner QD Protocol and one for Modbus RTU. Both connections can be used simultaneously.

The electrical signal arrangement of the RJ45 connector is shown as follows:



The QBus data link uses the same communication protocol as is used for IrDA communication. This is used for the Master / Slave function (refer to the Advanced User Guide for further information). Up to 62 slaves can be connected to one master drive.

The Modbus interface allows connection to a Modbus RTU network as described below.

9.2 Modbus RTU Communications

9.2.1. Modbus Telegram Structure

The Fenner QD:Neo supports Master / Slave Modbus RTU communications, using the 03 Read Holding Registers and 06 Write Single Holding Register commands. Many Master devices treat the first Register address as Register 0; therefore it may be necessary to convert the Register Numbers detail in section 0 by subtracting 1 to obtain the correct Register address.

The telegram structure is as follows:-

Command 03 - Read Holding Registers					
Master Telegram			Slave Response		
		Length			Length
Slave Address	1	Byte	Slave Address	1	Byte
Function Code (03)	1	Byte	Starting Address	1	Byte
1st Register Address	2	Bytes	1st Register Value	2	Bytes
No. of Registers	2	Bytes	2nd Register Value	2	Bytes
CRC Checksum	2	Bytes	Etc...		
			CRC Checksum	2	Bytes

Command 06 - Write Single Holding Register					
Master Telegram			Master Telegram		
		Length			Length
Slave Address	1	Byte	Slave Address	1	Byte
Function Code (06)	1	Byte	Function Code (06)	1	Byte
Register Address	2	Bytes	Register Address	2	Bytes
Value	2	Bytes	Register Value	2	Bytes
CRC Checksum	2	Bytes	CRC Checksum	2	Bytes

9.2.2 Modbus Control & Monitoring Registers

The following is a list of accessible Modbus Registers available in the Fenner QD:Neo drive.

- When Modbus RTU is configured as the Fieldbus option (P5-01 = 0, factory default setting), all of the listed registers can be accessed.
- Registers 1 and 2 can be used to control the drive providing that Modbus RTU is selected as the primary command source (P1-12 = 4)
- Register 3 can be used to control the output torque level providing that
 - The drive is operating in Vector Speed or Vector Torque motor control modes (P4-01 = 1 or 2)
 - The torque controller reference / limit is set for 'Fieldbus' (P4-06 = 3)
- Register 4 can be used to control the acceleration and deceleration rate of the drive providing that Fieldbus Ramp Control is enabled (P5-08 = 1)
- Registers 6 to 24 can be read regardless of the setting of P1-12

Register Number	Upper Byte	Lower Byte	Read Write	Notes
1	Command Control Word		R/W	Command control word used to control the Fenner QD:Neo when operating with Modbus RTU. The Control Word bit functions are as follows :- Bit 0 : Run/Stop command. Set to 1 to enable the drive. Set to 0 to stop the drive. Bit 1 : Fast stop request. Set to 1 to enable drive to stop with 2nd deceleration ramp. Bit 2 : Reset request. Set to 1 in order to reset any active faults or trips on the drive. This bit must be reset to zero once the fault has been cleared. Bit 3 : Coast stop request. Set to 1 to issue a coast stop command.
2	Command Speed Reference		R/W	Setpoint must be sent to the drive in Hz to one decimal place, e.g. 500 = 50.0Hz
3	Command Torque Reference		R/W	Setpoint must be sent to the drive in % to one decimal place, e.g. 2000 = 200.0%
4	Command Ramp Times		R/W	This register specifies the drive acceleration and deceleration ramp times used when Fieldbus Ramp Control is selected (P5-08 = 1) irrespective of the setting of P1-12. The input data range is from 0 to 60000 (0.00s to 600.00s)
6	Error Code	Drive Status	R/W	This register contains 2 bytes. The Lower Byte contains an 8 bit drive status word as follows :- Bit 0 : 0 = Drive Disabled (Stopped), 1 = Drive Enabled (Running) Bit 1 : 0 = Drive Healthy, 1 = Drive Tripped The Upper Byte will contain the relevant fault number in the event of a drive trip. Refer to section 11.1 for a list of fault codes and diagnostic information
7	Output Frequency		R	Output frequency of the drive to one decimal place, e.g. 123 = 12.3 Hz
8	Output Current		R	Output current of the drive to one decimal place, e.g. 105 = 10.5 Amps
9	Output Torque		R	Motor output torque level to one decimal place, e.g. 474 = 47.4 %
10	Output Power		R	Output power of the drive to two decimal places, e.g. 1100 = 11.00 kW
11	Digital Input Status		R	Represents the status of the drive inputs where Bit 0 = Digital Input 1 etc.
20	Analog Level 1		R	Analog Input 1 Applied Signal level in % to one decimal place, e.g. 1000 = 100.0%
21	Analog Level 2		R	Analog Input 2 Applied Signal level in % to one decimal place, e.g. 1000 = 100.0%
22	Pre Ramp Speed Reference		R	Internal drive frequency setpoint
23	DC Bus Voltages		R	Measured DC Bus Voltage in Volts
24	Drive Temperature		R	Measured Heatsink Temperature in °C

9.2.3 Modbus Parameter Access

All User Adjustable parameters (Groups 1 to 5) are accessible by Modbus, except those that would directly affect the Modbus communications, e.g.

- P5-01 Communication Protocol Select
- P5-02 Drive Fieldbus Address
- P5-03 Modbus RTU Baud Rate
- P5-04 Modbus RTU Data Format

All parameter values can be read from the drive and written to, depending on the operating mode of the drive – some parameters cannot be changed whilst the drive is enabled for example.

When accessing a drive parameter via Modbus, the Register number for the parameter is the same as the parameter number, E.g. Parameter P1-01 = Modbus Register 101.

Modbus RTU supports sixteen bit integer values, hence where a decimal point is used in the drive parameter, the register value will be multiplied by a factor of ten,

E.g. Read Value of P1-01 = 500, therefore this is 50.0Hz.

For further details on communicating with drive using Modbus RTU, please refer to your local Fenner Authorised Distributor.

10.0 Technical Data

10.1 Environmental

Ambient temperature Operational	:	-10...50°C (IP20 units), 40°C (IP55 units)
Storage	:	-40°C...60°C
Max altitude for rated operation	:	1000m
Derating above 1000m (to 400m max)	:	1% / 100m
Relative Humidity	:	<95% (non condensing)

Note: Drive must be frost and moisture free at all times. Installation above 2000m is not UL approved.

10.2 Output Power and Current Ratings

The following tables provide the output current rating information for the various Fenner QD:Neo models. It is also recommended that the selection of the correct Fenner QD:Neo is based upon the motor full load current at the incoming supply voltage.

200-240 Volt (+/- 10%) 1 Phase Input, 3 Phase Output

kW	HP	Nominal Input Current	Fuse or MCB (Type B)		Supply Cable Size		Nominal Output Current	Motor Cable Size		Maximum Motor Cable Length	Recommended Brake Resistance
			Non UL	UL	mm	AWG/kcmil		mm	AWG		
0.75	1	10.5	16	15	2.5	12	4.3	1.5	14	100	100
1.5	2	16.2	20	20	4	10	7	1.5	14	100	50
2.2	3	23.8	25	25	10	8	10.5	1.5	14	100	35

NOTE:

- The maximum motor cable length stated applies to using a shielded motor cable. When using an unshielded cable, the maximum cable length limit may be increased by 50%. When using the Fenner recommended output choke, the maximum cable length may be increased by 100%
- The PWM output switching from any inverter when used with a long motor cable length can cause an increase in the voltage at the motor terminals, depending on the motor cable length and inductance. The rise time and peak voltage can affect the service life of the motor. Fenner recommend using an output choke for motor cable lengths of 50m or more to ensure good motor service life
- For UL compliant installation, use Copper wire with a minimum insulation temperature rating of 70°C, UL Class CC or Class J Fuses

200-240 Volt (+/-10%) 3 Phase Input, 3 Phase Output

kW	HP	Frame Size	Nominal Input Current	Fuse or MCB (type B)	Supply Cable Size		Nominal Output Current	150% Output Current 60 secs	Motor Cable Size		Max Motor Cable Length	Optional Brake Resistor	
					mm²	AWG			mm²	AWG		Min	Rec
			Amps	Amps			Amps	Amps			m	Ω	
0.75	1	2	5.7	10	1.5	14	4.3	6.45	1.5	14	100	25	100
1.5	2	2	8.4	10	1.5	14	7	10.5	1.5	14	100	25	100
2.2	3	2	13.1	16	2.5	12	10.5	15.75	1.5	14	100	25	50
4	5	3	17.3	25	4	10	18	27	4	12	100	20	50
5.5	7.5	4	25	32	6	8	24	36	4	10	100	12	22
7.5	10	4	46.6	50	10	6	39	57	6	8	100	12	22
11	15	4	54.1	63	16	4	46	69	10	6	100	12	12
15	20	5	69.6	80	25	2	61	90.5	16	4	100	6	6
18.5	25	5	76.9	80	25	2	72	54	16	4	100	6	6
22	30	5	92.3	100	35	1	90	67.5	25	2	100	6	6
30	40	6	116.9	125	50	2/0	110	82.5	25	1/0	100	3	3
37	50	6	150.2	160	70	3/0	150	112.5	35	2/0	100	3	3
45	60	6	176.5	200	90	-	180	135	50	3/0	100	3	3
55	75	7	211	250	150	-	202	151.5	150	4/0	100	3	3
75	100	7	259	315	2 x 120	-	248	180	2 x 120	-	100	3	3
90	120	7	314	400	2 x 120	-	312	225	2 x 120	-	100	3	3

380 - 480 Volt (+/-10%) 3 Phase Input, 3 Phase Output

kW	HP	Frame Size	Nominal Input Current	Fuse or MCB (type B)	Supply Cable Size		Nominal Output Current	150% Output Current 60 secs	Motor Cable Size		Max Motor Cable Length	Optional Brake Resistor	
			Amps	Amps	mm ²	AWG	Amps	Amps	mm ²	AWG	m	Min	Rec
												Ω	
0.75	1	2	3.1	6	1.5	14	2.2	3.3	1.5	14	100	80	400
1.5	2	2	4.8	10	1.5	14	4.1	6.2	1.5	14	100	80	200
2.2	3	2	7.2	16	2.5	14	5.8	8.5	2.5	14	100	80	200
4	5	2	10.8	16	2.5	12	9.5	14.3	2.5	12	100	80	100
5.5	7.5	3	13.3	16	2.5	12	14	21	2.5	12	100	47	100
7.5	10	3	18.5	25	4	10	18	27	4	10	100	47	50
11	15	3	26.5	35	6	8	25 (24)	37.5 (36)	4	8	100	40	50
15	20	4	32.9	50	6	6	30	45	6	6	100	22	22
18.5	25	4	46.6	50	10	6	39	58.5	10	6	100	22	22
22	30	4	54.1	63	16	4	46	69	16	4	100	22	22
30	40	5	69.6	80	25	2	61	91.5	25	2	100	12	12
37	50	5	76.9	80	25	2	72	108	25	2	100	12	12
45	60	5	92.3	100	35	1	90	135	35	1	100	12	12
55	75	6	116.9	125	50	2/0	110	165	50	2/0	100	6	6
75	120	6	150.2	160	70	3/0	150	225	70	3/0	100	6	6
90	150	6	176.5	200	90	-	180	270	90	-	100	6	6
110	175	7	217.2	250	150	-	202	303	150	-	100	4.7	6
132	200	7	255.7	315	2 x 120	-	240	360	2 x 120	-	100	4.7	6
160	250	7	302.4	400	2 x 120	-	300	450	2 x 120	-	100	4.7	6

- The maximum motor cable length stated applies to using a shielded motor cable. When using an unshielded cable, the maximum cable length limit may be increased by 50%. When using the Invertek Drives recommended output choke, the maximum cable length may be increased by 100%.
- The PWM output switching from any inverter when used with a long motor cable length can cause an increase in the voltage at the motor terminals, depending on the motor cable length and inductance. The rise time and peak voltage can affect the service life of the motor. Fenner recommend using an output choke for motor cable lengths of 50m or more to ensure good motor service life
- For UL compliant installation, use Copper wire with a minimum insulation temperature rating of 70°C, UL Class CC or Class J Fuses
- Data values shown in *Italics* are provisional

10.3 Additional Information for UL Approved Installations

The Fenner QD:Neo is designed to meet the UL requirements. In order to ensure full compliance, the following must be fully observed.

Input Power Supply Requirements


Supply Voltage	200 – 240 RMS Volts for 230 Volt rated units, + / - 10% variation allowed, 240 Volt RMS Maximum 380 – 480 Volts for 400 Volt rated units, + / - 10% variation allowed, Maximum 500 Volts RMS			
Imbalance	Maximum 3% voltage variation between phase – phase voltages allowed All Fenner QD:Neo units have phase imbalance monitoring. A phase imbalance of > 3% will result in the drive tripping. For input supplies which have supply imbalance greater than 3% (typically the Indian sub- continent & parts of Asia Pacific including China) Fenner recommends the installation of input line reactors. Alternatively, the drives can be operated as a single phase supply drive with 50% derating.			
Frequency	50 – 60Hz + / - 5% Variation			
Short Circuit Capacity	Voltage Rating	Min kW (HP)	Max kW (HP)	Max Supply Short Circuit Current
	230 V	0.37 (0.5)	18.5 (25)	5kA rms (AC)
	230 V	22 (30)	75 (100)	10kA rms (AC)
	400 / 460 V	0.75 (1)	37 (50)	5kA rms (AC)
	400 / 460 V	45 (60)	132 (200)	10kA rms (AC)
	400 / 460 V	160 (250)	250 (350)	18kA rms (AC)
All the drives in the above table are suitable for use on a circuit capable of delivering not more than the above specified maximum short-circuit Amperes symmetrical with the specified maximum supply voltage.				
Incoming power supply connection must be according to section 4.3				
All Fenner QD:Neo units are intended for indoor installation within controlled environments which meet the condition limits shown in section 10.1				
Branch circuit protection must be installed according to the relevant national codes. Fuse ratings and types are shown in section 10.2				
Suitable Power and motor cables should be selected according to the data shown in section 10.2				
Power cable connections and tightening torques are shown in section 3.4				
Fenner QD:Neo provides motor overload protection in accordance with the National Electrical Code (US).				

11. Troubleshooting

11.1 Fault Messages

Fault Code	No	Description	Corrective Action
no-Fault	00	No Fault	Displayed in P0-13 if no faults are recorded in the log
01-b	01	Brake channel over current	Ensure the connected brake resistor is above the minimum permissible level for the drive – refer to the ratings shown in section 10.4. Check the brake resistor and wiring for possible short circuits.
02-br	02	Brake resistor overload	The drive software has determined that the brake resistor is overloaded, and trips to protect the resistor. Always ensure the brake resistor is being operated within its designed parameter before making any parameter or system changes. To reduce the load on the resistor, increase deceleration the time, reduce the load inertia or add further brake resistors in parallel, observing the minimum resistance value for the drive in use.
03-l	03	Instantaneous over current on drive output. Excess load on the motor.	Fault Occurs on Drive Enable Check the motor and motor connection cable for phase – phase and phase – earth short circuits. Check the load mechanically for a jam, blockage or stalled condition Ensure the motor nameplate parameters are correctly entered, P1-07, P1-08, P1-09. If operating in Vector mode (P4-01 – 0 or 1), also check the motor power factor in P4-05 and ensure an autotune has been successfully completed for the connected motor. Reduced the Boost voltage setting in P1-11 Increase the ramp up time in P1-03 If the connected motor has a holding brake, ensure the brake is correctly connected and controlled, and is releasing correctly Fault Occurs When Running If operating in Vector mode (P4-01 – 0 or 1), reduce the speed loop gain in P4-03
04-lt-trP	04	Drive has tripped on overload after delivering >100% of value in P1-08 for a period of time.	Check to see when the decimal points are flashing (drive in overload) and either increase acceleration rate or reduce the load. Check motor cable length is within the limit specified for the relevant drive in section 10.4 Ensure the motor nameplate parameters are correctly entered in P1-07, P1-08, and P1-09 If operating in Vector mode (P4-01 – 0 or 1), also check the motor power factor in P4-05 and ensure an autotune has been successfully completed for the connected motor. Check the load mechanically to ensure it is free, and that no jams, blockages or other mechanical faults exist
05-P5-trP	05	Instantaneous over current on drive output.	Refer to fault 3 above
06-voct	06	Over voltage on DC bus	The value of the DC Bus Voltage can be displayed in P0-20 A historical log is stored at 256ms intervals prior to a trip in parameter P0-36 This fault is generally caused by excessive regenerative energy being transferred from the load back to the drive. When a high inertia or over hauling type load is connected. If the fault occurs on stopping or during deceleration, increase the deceleration ramp time P1-04 or connect a suitable brake resistor to the drive. If operating in Vector Mode, reduce the speed loop gain P4-03 If operating in PID control, ensure that ramps are active by reducing P3-11
07-voct	07	Under voltage on DC bus	This occurs routinely when power is switched off. If it occurs during running, check the incoming supply voltage, and all connections into the drive, fuses, contactors etc.
08-ot	08	Heatsink over temperature	The heatsink temperature can be displayed in P0-21. A historical log is stored at 30 second intervals prior to a trip in parameter P0-38 Check the drive ambient temperature Ensure the drive internal cooling fan is operating Ensure that the required space around the drive as shown in sections 0 and 3.8 has been observed, and that the cooling airflow path to and from the drive is not restricted Reduce the effective switching frequency setting in parameter P2-24 Reduce the load on the motor / drive
09-ut	09	Under temperature	Trip occurs when ambient temperature is less than -10°C. The temperature must be raised over -10°C in order to start the drive.
10-P-def	10	Factory Default parameters have been loaded	Press STOP key, the drive is now ready to be configured for the required application
11-etrP	11	External trip	E-trip requested on control input terminals. Some settings of P1-13 require a normally closed contactor to provide an external means of tripping the drive in the event that an external device develops a fault. If a motor thermistor is connected check if the motor is too hot.
12-065	12	Communications fault	Communications lost with PC or remote keypad. Check the cables and connections to external devices
13-rlt-dc	13	Excessive DC ripple	The DC Bus Ripple Voltage level can be displayed in parameter P0-22 A historical log is stored at 20ms intervals prior to a trip in parameter P0-39 Check all three supply phases are present and within the 3% supply voltage level imbalance tolerance. Reduce the motor load - If the fault persists, contact your local Fenner distributor
14-P-loss	14	Input phase loss trip	Drive intended for use with a 3 phase supply, one input phase has been disconnected or lost.
15-h 0-l	15	Instantaneous over current on drive output.	Refer to fault 3 above

Fault Code	No	Description	Corrective Action
th-F _{ut}	16	Faulty thermistor on heatsink	Contact your Fenner authorised distributor
dRtR-F	17	Internal memory fault	Parameters not saved, defaults reloaded. Try again. If problem recurs, refer to your Fenner authorised distributor
4-20F	18	4-20mA signal lost	The reference signal on Analog Input 1 or 2 (Terminals 6 or 10) has dropped below the minimum threshold of 3mA. Check the signal source and wiring to the drive terminals.
dRtR-E	19	Internal memory fault	Parameters not saved, defaults reloaded. Try again. If problem recurs, refer to your Fenner authorised distributor
U-dEF	20	User parameter defaults	User Parameter defaults have been loaded. Press the Stop key.
F-Ptc	21	Motor PTC Over temperature	The connected motor PTC device has caused the drive to trip
FAn-F	22	Cooling fan fault	Check and if necessary, replace the drive internal cooling fan
0-hERt	23	Ambient temperature too high	The measured temperature around the drive is above the operating limit of the drive. Ensure the drive internal cooling fan is operating Ensure that the required space around the drive as shown in sections 0 and 3.8 has been observed, and that the cooling airflow path to and from the drive is not restricted Increase the cooling airflow to the drive Reduce the effective switching frequency setting in parameter P2-24 Reduce the load on the motor / drive
0-tor9	24	Maximum torque limit	The output torque limit has exceeded the drive capacity or trip threshold Reduce the motor load, or increase the acceleration time
U-tor9	25	Output torque too low	Active only when hoist brake control is enabled P2-18 = 8. The torque developed prior to releasing the motor holding brake is below the preset threshold. Contact your local Fenner authorised distributor for further information on using the Fenner QD:Neo in hoist applications.
DUt-F	26	Drive output fault	Drive output fault
Enc-01	30	Encoder feedback faults (Only visible when encoder module is fitted and enabled)	Encoder communications/data loss
Enc-02	31		Encoder speed error. The error between the measured encoder feedback speed and the Fenner QD estimated rotor speed is greater than the pre-set limit allowed
Enc-03	32		Incorrect encoder PPR count set in parameters
Enc-04	33		Encoder channel A fault
Enc-05	34		Encoder Channel B fault
Enc-06	35		Encoder channels A & B fault
Enc-07	36		RS 485 channel error (servo)
Enc-08	37		IO comms loss (servo)
Enc-09	38		Wrong type encoder (servo)
Enc-10	39		KTY trip (servo)
RtF-01	40	Autotune failed	Measured motor stator resistance varies between phases. Ensure the motor is correctly connected and free from faults. Check the windings for correct resistance and balance.
RtF-02	41		Measured motor stator resistance is too large. Ensure the motor is correctly connected and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
RtF-03	42		Measured motor inductance is too low. Ensure the motor is correctly connected and free from faults.
RtF-04	43		Measured motor inductance is too large. Ensure the motor is correctly connected and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
RtF-05	44		Measured motor parameters are not convergent. Ensure the motor is correctly connected and free from faults. Check that the power rating corresponds to the power rating of the connected drive.
Sc-t01	50	Modbus comms fault	A valid Modbus telegram has not been received within the watchdog time limit set in P5-06 Check the network master / PLC is still operating Check the connection cables Increase the value of P5-06 to a suitable level
Sc-t02	51	CAN open comms trip	A valid CAN open telegram has not been received within the watchdog time limit set in P5-06 Check the network master / PLC is still operating Check the connection cables Increase the value of P5-06 to a suitable level
Sc-t03	52	Communication option module fault	Internal communication to the inserted Communication Option Module has been lost. Check the module is correctly inserted
Sc-t04	53	IO card comms trip	Internal communication to the inserted Option Module has been lost. Check the module is correctly inserted



82-P2MAN-FN_V1.10